

# EG Series Screw Air Compressor

Operation, Maintenance and Parts Manual





# **Product Manual**

EG Series Electric Powered Screw Air Compressor

## EG 18 - 100.0, 125.0

Air - Cooled, Standard + VFD 460V, 3Ph, 60Hz

## $\bigcirc$

## **ELGI EQUIPMENTS LIMITED**

Coimbatore, TN - 641 005

Part / Document No. 019000383

## Contact Info: ELGI EQUIPMENTS LIMITED

Coimbatore, TN - 641 005, India Tel : 91 - 422 2589555 Fax : 91 - 422 2573697 (Domestic Business) Fax : 91 - 422 2589401 (International Business) E-mail : enquiry@elgi.com Website : www.elgi.com

## **Machine Identification and Sale Record**

Owner's name / Company name	:
Phone number	:
Contact person	:
E-Mail address/ Phone number	
Model	:
Fab. No.	:
Year of manufacture	:
Motor	:
Capacity	:
Rated pressure	:bar.g (psi.g)
Date of delivery	:
Date of commissioning	:
Dealer name/address	:
Dealer's signature	:



The warranty on the compressor is valid only if all the details above are filled in and the dealer stamps and signs this page. This report must reach the Regional Office/Head Office of ELGi within seven days of commissioning date.

ELGi

# **Table of Contents**

	Chapter	Page No.
1.0	About ELGi	1.7
2.0	General functional description	2.1
3.0	GA drawing, P&I diagram	3.1
4.0	Technical data	4.1
5.0	Installation and operation	5.1
6.0	Maintenance	6.1
7.0	Controller	7.1
8.0	Air inlet and control system	8.2
9.0	Drive system	9.1
10.0	Discharge system	10.1
11.0	Cooling system	11.1
12.0	Lubrication system	12.1
13.0	Base and canopy system	13.1
14.0	Spare kit details	14.1
15.0	Electrical drawings	15.1
16.0	VFD settings	16.1



## **1.0** About ELGi



ELGi, established in 1960, designs and manufactures a wide range of air compressors. The company has gained its reputation for design and manufacture of screw compressors through strategic partnerships and continuous research and development. Over the years, it has emerged as a multi-product, multi-market enterprise providing total compressed air solutions to all segments. ELGi's design capabilities translated into a wide range of products ranging from oil-lubricated and oil-free rotary screw compressors, reciprocating compressors and centrifugal compressors.

ELGi is one of the few companies in the world capable of manufacturing wide range of airends and compressor packages. ELGi has most modern manufacturing facilities with high precision grinding machines, turning centres, CNC horizontal and vertical machining centres and also the latest self measurement technology to maintain precise, aerospace manufacturing tolerances. ELGi's manufacturing plants are ISO and EOHS certified.

Over two million ELGi compressors are powering business in 70+ countries worldwide. The company offers a strong sales and service network with a well-knit distribution network of dealers and distribution, worldwide. ELGi has its own manufacturing operations in India, Italy and USA with subsidiary offices in Australia, Bangladesh, Brazil, China, Indonesia, Italy, Malaysia, Middle East, Sri Lanka and Thailand. The company is fast expanding its global footprint, attracting distributors and customers with its new generation products.

#### Need help...?

#### In India

You can contact ELGi customer care system (ECCS) to take care of customer complaints. The ELGi CCS works for six days a week from 08:30 to 21:30 IST (Monday to Saturday). The complaints can be logged by calling any of the following toll free numbers or by e-mail.

- Toll free : 1800 425 3544
- E-Mail : <u>ccs@elgi.com</u>

#### Website : <u>www.elgi.com</u>

Before making service request for your compressor, keep ready the details printed on the name plate of the compressor and machine identification and sale record of this manual. When ordering spare parts, refer to the lists provided in the parts manual and identify the part number. Specify the part number and quantity, in addition to the name plate details.

- • • • -

Refer "ELGi services" for more details about ECCS under chapter "Maintenance".

# 2.0 General functional description

Contents	Page No.
2.1 Using the manual	2.2
2.1.1. Definitions and symbols	2.2
2.2 Introduction	2.3
2.3 Safety	2.4
2.3.1 Precautions during installation	2.4
2.3.2 Precautions during operation	2.5
2.3.3 Precautions during maintenance	2.7
2.4 Functional description	2.9
2.4.1 Air circuit	2.9
2.4.2 Oil circuit	2.9
2.4.3 Drive system	2.9
2.4.4 Control system	2.10
2.4.5 For retro-fitment of Standalone VFD with Compressor (C) version in field	2.10



# ELGi

## 2.1 Using the manual

This operation and maintenance manual has been specially designed keeping the customer in mind so that the person can get the most out of this EG compressor. Before starting the compressor, it is requested that the manual should be read thoroughly. It contains vital information about installation, commissioning, operation and useful tips on maintenance to keep the compressor as good as new, year after year. The manual has been prepared with utmost care to help you understand the various systems of the compressor, along with descriptions, information and illustrations.

Following chapters are provided to help operate the compressor in its best way.

- **Safety** safety precautions that must be followed while using the compressor.
- **Technical specifications** technical details about the compressor.
- **Installation and commissioning -** all site requirements, procedures to be followed during installation, commissioning, preservation etc.
- Functional description parts, their function and working.
- **Operating instructions** to operate the compressor properly.
- **Maintenance** how to do the maintenance for the compressor and their intervals.
- **Troubleshooting** identification and solving the problems.
- **Decommissioning** how to decommission the compressor, its disposal etc.
- **ELGi services** services from ELGi: CCS, air audit, spare parts
- Appendix conversion tables, torque values, service log book

Refer to the parts manual to identify the part number of the required spare. Mention the Fab number, model and part number while ordering.

# This manual must be made available to the compressor operating and maintenance personnel at all times.





## 2.1.1 Definitions and symbols

This information is related to your safety and also to prevent any problems relevant to the equipments used. To help recognize this information better, the symbols are illustrated in section "**safety**".

All the information, illustrations and specifications in this manual are based on the latest product information at the time of preparation of the manual. Product improvement is a continuous process in ELGi. The details in this manual are likely to change without notice and ELGi reserves the right to incorporate such changes.

## NOTE

Note clarifies procedures or conditions which may otherwise be misinterpreted or overlooked. Note may also be used to clarify apparently contradictory or confusing situations.

## 

Warning calls attention to dangerous or hazardous conditions inherent to the operation, cleaning and maintenance of the compressor which may result in fatal accident and personal injury of the operator or other staff

## **A** CAUTION

Caution is to draw attention to a procedure which, if not done correctly can lead to compressor damage.

## 2.2 Introduction



Welcome to ELGi customer family. ELGi compressors are the source of compressed air in various segments across the globe.

ELGi compressors are known for

- Greatest reliability
- Fewer maintenance interval
- Ease of use
- Highest safety

ELGi screw compressor is designed to give

- High energy efficiency
- Low maintenance cost
- High discharge air quality

All the above assures a low life-cycle cost.

The rotors incorporate a specially designed **eta-v profile** – ELGi patented profile-which emphasizes on improving reliability, performance and efficiency. Eta-v profile is the latest and the most energy efficient profile in the industry globally, assuring consistent performance during entire life of the compressor. ELGi screw air compressors have a compact design and compressor run with low noise or vibrations. The capacity control system ensures optimum air intake during start up, normal running and unloading stages, minimizing power consumption. The oil separation system ensures that maximum oil is separated from the compressed air, ensuring the best air quality with very little oil carry-over.

## Uptime

At ELGi, we are changing the way you look at compressed air systems. It's no longer just about delivering air. It's about delivering uptime. Our uptime design ensures that the compressors would run cooler, cleaner and longer with longer service intervals. The uptime components are bests in quality keeps your compressor to run smoothly, efficiently and profitably. With uptime assurance we back our pledge, with industry-leading warranties, parts availability, loaner compressors and call centres staffed by experts. We thank you for purchasing ELGi compressor and assure you the best service during entire life of compressor.

## **EG Series**

Your EG Series compressor belongs to a family of rotary screw compressors from ELGi. The compressor has only two moving parts: the two rotors. A thin film of oil separates the rotors to prevent wear. This also means that the reliability of the compressor is unsurpassed.

The screw compressor technology ensures that output capacity never diminishes even after many years of operation. It involves a continuous flow of air through helical cavities in the screw, ensuring pulsation-free compressed air delivery. The design of the EG Series gives you a compact and selfcontained compressor. Because it contains no reciprocating parts, it runs quietly and free of vibrations. The discharge temperature of the coolant oil is low, less than 90°C (195°F), under normal conditions and therefore prevents carbonized oil from forming in the compressor.

## **Salient Features**

- Three-stage air filtration
- Improved air filter life cycle
- Noise-free package suitable for in-house operations
- Variable capacity control system\*
- High volumetric efficiency
- Efficient air-oil separation by OSBIC (Oil Separation By Impact and Centrifugal action)
- Reliable fan that works even at high temperature
- Isolated cooling system
- Robust cooling system
- Industrial designed canopy
- Compact and hardly space-intensive
- Split type oil & after coolers for easy serviceability
- Flush type panels for easy handling
- Anti-vibration mounts for restricted vibration
- Increased life of consumables
- Integrated VFD (Variable Frequency Drive) and dryer\*.
- Zero-leak flanged joints.
- Oil carry over < 1 ppm
- Advanced Neuron controller
- Globally certified product CE / UL and other country specific approvals.
- \* For selected models.

## 2.3 Safety

The operator must follow the safe working practices, instructions, procedures that this manual describes for safe operation. The maintenance personnel must be adequately trained, and have read and thoroughly understood this 'Operation and maintenance manual'. Decals are affixed at specific locations of the compressor and they illustrate very important safety precautions.

## 2.3.1 Precautions during installation

 Ensure that you fasten all loose parts before lifting. Select the appropriate lifting equipment by considering the local safety regulations, size and weight of the compressor.
 Operate the lifting equipment carefully within the safe operating limits. Ensure all necessary personal protective equipment's (PPEs) is close at hand during this operation.



- Maintain a cool and clean ambient for the compressor and ensure that the air inlet is not obstructed. Make arrangements to reduce the moisture entry through the incoming air.
- Remove protection such as caps, plugs, desiccant bags before connecting the air line pipes.
- Remove the red colored protective clamps from the airend and motor while commissioning the compressor.



- Do not use frayed, damaged or worn hoses. Distribution pipes and connections must be of the correct size and suitable for working pressure.
- Make sure that the aspirated air by the compressor is free of flammable fumes, vapors and particles, to prevent internal fire or explosion.
- For remotely controlled compressors and auto-start compressors, provide a clear caution stating:
   "DANGER" – Remotely controlled machine and will start without notice



• Ensure the operator is located far away from the intake of the compressor.

ELGi

- Position the after-cooler discharge pipe in a way that it is free to expand under heat and is not in contact with or close to flammable materials.
- Do not exert external force on the air outlet valve and keep the connected pipe always free of strain.
- Make available adequate cooling air must be made available for the compressor particularly air cooled compressors. Make sure that exhausted air does not circulate back to the intake or cooling system.
- Make the electrical connections according to the legal standards and earth the compressor suitably. Provide a sufficient number of fuses and other protective devices to protect the compressor against short circuits. Good practice is to provide an isolating switch nearby the compressor.
- Install manual valves behind non-return valves (NRV) to isolate each compressor in multi-compressor systems. Do not rely on NRV for isolating pressure systems.
- Do not bypass, remove or adjust the safety devices or other attachments residing on the compressor. Every installed pressure vessel or auxiliary outside the compressor should have pressure relieving device or devices, as required.





Danger! Be aware that compressed air used for breathing or food processing must meet O.S.H.A.

1910.134 or F.D.A. 21 C.F.R. 178.3570 regulations. Failure to do so may cause severe injury or death.

- Insulate or use protective guards to cover pipes or other parts that may exceed 80°C (176°F). High-temperature pipes must have a clear marking as potentially dangerous.
- Position the compressor on level surface. In case of inclined surface, contact ELGi.
- Do not allow compressed air to come in contact with food and related items unless they are compressed airtreated specifically.
- Be aware that this air compressor is intended for generating only industrial-use compressed air.

## 2.3.2 Precautions during operations

- When switching on remotely controlled compressors ensure that no one is checking or working on the compressor at that time.
- Before starting, ensure that no tools or any loose parts remain inside the compressor.
- Do not operate the compressor if a possibility exists that it could inhale flammable or toxic fumes, vapors or particles.
- Do not operate the compressor below or above its operating limits.
- Wear ear protectors if you work in an environment where the sound pressure level reaches or exceeds 90 dB (A).
- Keep all the compressor doors shut during operation.
   For carrying out routine checks, the doors should open only for short durations not more than 10 minutes.
   Wear ear protectors when opening a door.
- Keep hands, feet, floors, controls and walking surfaces clean and free of water or other liquid to minimize the possibility of slips and falls.

#### **Pressure release**

- Know that annual servicing of the safety valve is necessary. It should be checked at the prescribed pressure for operation.
- Use correct tools for maintenance and repair work.
   Do not allow the manufacturers' rated safe operating pressure to exceed for pipes, valves, filters and other fittings.
- It is hazardous to point the compressed air directly towards any personnel. Keep personnel out of the line of the discharge air when opening hoses or other points of compressed air discharge.
- Use only the correct type and size of hose end fittings and connections. When blowing through a hose or airline ensure that the open end stays securely. A free end will whip and may cause injury. Make sure to

#### depressurize a hose fully before disconnecting it.



- Release all the pressure in the compressor system before servicing or performing any maintenance activity.
- Do not engage in horseplay with air hoses. Serious injury or death may result.
- Do not use air at a pressure greater than 2.5 bar.g (36 psi.g) for cleaning purpose.
- Open the oil fill cap only when the compressor is not running and is not pressurized. Shut down the compressor and bleed the receiver tank to zero internal pressure before removing the cap.

#### **Fire and explosion**



- Clean up spills of lubricants or other combustible substances immediately.
- Shut down the compressor and allow it to cool down before checking or adding oil. Remove sparks, flames and other sources of ignition away from the compressor.
- Do not permit smoking in the vicinity of the compressor.
- Do not use flammable solvents for cleaning purposes.
- Keep electrical wiring and other terminals in good condition. Replace any wiring that has cracked, cut, abraded or otherwise degraded insulation. Keep all terminals clean and tight.
- Keep grounded conductive objects such as tools away from exposed live electrical parts like terminals to avoid arcing, which might serve as a source.
- Keep oily rags, trash, dry leaves, litter or other combustibles out of and away from the compressor.
- Do not operate the compressor without a proper flow of cooling air or with an inadequate flow of lubricant or with a degraded lubricant.
- Do not attempt to operate the compressor in a hazardous environment of any classification unless the compressor has been specially designed and manufactured for explosive applications.

## **Moving Parts**



- Rotating fan blades can cause serious injury. Disconnect power supply before attempting service.
- Keep compressor doors closed except when servicing or during maintenance. The sound damping material on the inner side of the compressor body should not be removed or tampered with.
- Wear snug-fitting clothing and tie long hair when working around the compressor, especially when hot or moving parts such as the cooler, the airend, the thermal valve, the main motor or the fan motor are exposed.
- Keep hands, arms and clothing away from couplings, fans/belts and other moving parts.
- Do not attempt to operate the compressor with the fan guards, coupling guards/belt guards or other guards removed.



• Keep hands, feet, floor, controls and walking surfaces clean and free of fluid, water or other liquids to minimize the possibility of slips and falls.

### Hot surfaces



- Avoid bodily contact with hot oil and hot surfaces like cooler, pipes etc.
- Keep all parts of the body away from all points of air discharge.
- Keep a first aid kit handy. Seek medical assistance promptly in case of injury. Do not ignore small cuts and burns.

## Toxic and irritating substances

- Do not use air from the compressor for breathing.
- Always wear safety equipment while operating the compressor. Refer OSHA safety standards.
- Do not allow compressed air to come into contact with any edible items.
- In the event of ingestion of oils, coolants or lubricants used in the compressor, seek medical treatment promptly. In case you come in contact with such substances, wash with soap and water. Use MSDS for oil to know more on this.
- If warm cooling air from the compressor is being used in air heating systems, e.g. to warm up a work room, take precautions against air pollution and possible contamination of the breathing air.

## **Electric shock**

- Keep all parts of the body and any handheld tools or other conductive objects away from exposed live parts of the electrical system.
- Stand on a dry or insulating surface and do not contact any other part of the compressor when making adjustments or repairs to exposed live parts of the electrical system.





- Before switching on the compressor ensure that proper earthing is done as per recommendation.
- Make all adjustments or repairs with one hand. This minimizes the risk of creating a current path through the heart.
- Conduct repairs only in a clean, dry, well-lit and ventilated area.
- Do not leave the compressor unattended with open electrical enclosures. If necessary to do so, disconnect the power to the compressor at the source and lock it out so that power is not in advertently restored.
- Disconnect, lock out, and tag the power source prior to attempting repairs or adjustments, turning the compressor manually or handling ungrounded conductors.
- All electrical installation must be in accordance with recognized electrical codes and any local health & safety codes.
- Recognize that only authorized and qualified trained personnel should carry out any electrical work on the compressor.
- Regularly check that all electrical connections are tight and in good condition.

## Periodically check whether

- All guards are in place and securely fastened.
- All hoses and pipes inside the compressor are in good condition, secure and not rubbing against each other.
- Any leaks exists.
- All fasteners are tight.
- All electrical leads are secure and in good order.
- Safety valves and other pressure relief devices are not obstructed by dirt or paint.
- Air outlet valve, i.e. pipes, couplings, manifolds, valves, hoses, etc. are in good repair, free of wear or abuse.
- The air-oil tank is properly grounded.

## 2.3.3 Precautions during maintenance

- Use safety glasses and incorporate safe working practices before maintenance work.
- Use appropriate tools for all maintenance works.

• Use only genuine spare parts. Refer the **section "Use genuine spare parts"** in **"Maintenance"** chapter.



• Ensure that the compressor is cooled down before maintenance is performed.



- Springs under tension or compression store energy. Uncontrolled release of this energy can cause serious injury or death. Be cautious while performing the maintenance of components loaded with springs (for example minimum pressure valve, safety valve etc.).
- Display a warning sign that says **"Maintenance under progress, don't switch on"** near the start switch.
- Isolate the compressor from the air line (discharge) and disconnect the power by opening and locking the isolating switch before maintenance.
- Prior to attempting repairs or adjustments, disconnect the power at the source and verify at the compressor that the circuits have de-energized. This minimizes the possibility of accidental start-up or operation, especially when the compressor is remotely controlled.
- Open the oil filler cap only when the compressor is not running and is not pressurized. Shut down the compressor and bleed the receiver tank to zero internal pressure before removing the cap.



- If you are going to switch on remotely controlled compressors must ensure that nobody is checking or working on the compressor at that time. A warning sign near the equipment's start button is mandatory.
- Wait up to five minutes to ensure that the air in the airoil separator tank is released to start routing maintenance.



- Vent all internal pressure prior to opening any line, fitting, valve, drain plug, connection or other components such as filters. Vent pressure by popping up the safety valve.
- Display a maintenance chart near the compressor to easily identify the maintenance intervals of regular service items.



## 2.4 Functional description





## 2.4.1 Air circuit

The atmospheric air enters into the airend through the air intake system. The intake filters (pre filter and air filter) prevents the entry of foreign particles (such as dust) into the airend. The intake valve regulates the amount of air sucked into the airend. The opening and closing of the intake valve are controlled by the pneumatic pulse line actuated by an electrically controlled solenoid valve. The clog indicator fitted in the air filter turns red when the filter is clogged.

The filtered air enters into the airend where it mixes with the injected oil. The injected oil acts as a coolant to maintain optimum temperature. It also seals the leaks between the rotors and the housing and lubricates the bearings and gears. The airend consists of two counterrotating intermeshed helical screws - the male and the female rotors - which are driven by electric motor. The air -oil mixture is trapped between the rotors of the airend and is progressively compressed.

After being compressed, the air-oil mixture enters with high velocity into the air-oil separator tank where it undergoes a unique 3 stage separation process which removes maximum oil content. This highly efficient 3 stage separation process uses the impact velocity of air-oil mixture along with centrifugal action, which makes the mixture very lean. The final stage of this separation consists of passing the lean mixture through the air-oil separator element which leaves the air with an oil content of < 1 ppm.

The oil separated and collected in this element is then returned to the airend through the oil return line. The air passes through a minimum pressure valve (MPV). It maintains a minimum differential pressure which is required for circulation of oil within the compressor unit. The compressed hot air is cooled in the after cooler and is separated of any moisture content by the moisture separator. The cooled and moisture free compressed air is now discharged to the external receiver, ready to be used.

ELGi

## 2.4.2 Oil circuit

The oil in the air-oil separation tank after being separated is fed into the airend. The oil either gets diverted to the oil cooler or oil filter or both depending upon the temperature. The thermal valve governs and controls the oil flow path. The oil before being injected into the airend is filtered. An orifice is provided in oil flow path towards the airend to control the oil flow. The whole oil circulation circuit in the compressor is operated solely by the differential pressure maintained by the minimum pressure valve (MPV) and doesn't require any additional pump.

## 2.4.3 Drive system

The airend transmission is powered by an electric induction motor through a coupling. When the compressor is turned ON, the motor is started in star mode and takes 6 to 9 seconds to change over to delta mode. During this period the intake valve remains closed and thus the motor starts without load. In delta mode, the motor speed stabilizes, the solenoid valve energizes after 10 seconds of change-over to reduce load on the motor, the blow down valve is closes, intake valve opens and the compressor starts loading. For compressors with variable frequency drive (VFD), speed of the motor gradually increases within 30 seconds (ramp-up time) while the intake valve remains in the closed position. This ensures very little starting load. Next, the intake valve opens and the system starts building up pressure. An adaptor ring connects the airend and the motor. It also helps in maintaining the coupling alignment. The coupling element acts as a safety interlock and it is the first one to fail when coupling elements become over loaded. This architecture saves the whole drive system from failure. Malfunctioning of the coupling

element will result in noise and vibration. Anti-vibration mountings reside below the air end and the motor. This configuration reduces the transmission of vibration from airend and motor to the structure, reducing noise and ensuring reliability of mounted parts on the structure.

## 2.4.4 Control system

## Load - Unload

Depending on the demand for compressed air from the application at a particular time, the compressor needs to respond accordingly. The compressor, therefore operates in either loading or unloading mode to meet this requirement. The primary objective of these modes is to save energy and reduce wear and tear on the machine. The control system ensures a smooth start without overloading the motor. The compressor is started in star mode, during which most of the compressed air is vented to the atmosphere. This mechanism helps prevent overloading the motor. In delta mode the motor speed stabilizes, the solenoid valve energizes after 10 seconds of change-over to reduce load on the motor, the blow-down valve is closes, and the compressor starts loading.

When the receiver pressure reaches the maximum limit, a signal arrives the solenoid valve from the control system. Next, the inlet valve actuates and closes, and the compressor runs in unloading mode. If unloading mode continues for more than 5 minutes, i.e., compressed air is consumed and thus no decrease in pressure occurs, the system stops and switches to standby mode. If a drop in pressure occurs in the receiver, the compressor returns to loading mode automatically.

## Suction modulation

When you operate a compressor without VFD, capacity control occurs via a pressure regulator (for selected models). When the consumption of air is less than the FAD of the compressor, the line pressure will start increasing. Whenever the line pressure goes up constantly beyond the set pressure, the pressure regulator bleeds the excess air to the atmosphere thereby reducing the amount of flow into the actuator. The actuator is spring loaded, which, in turn, closes the intake valve slightly and enables capacity control. Similarly when the consumption of air is more than the FAD, the line pressure starts decreasing and the actuator progressively opens the intake valve. This regulation is called intake modulation by throttling.

## VFD modulation

VFD is an efficient way of controlling capacity as per demand. In a compressor with VFD the power of compressor varies proportionally with capacity reduction. The VFD tunes the frequency, thereby adjusting the speed based on the change in line pressure. The incoming flow will automatically reduce because of reduced speed of the motor. Conversely speed increases when line pressure goes down below working pressure.

# 2.4.5 For retro-fitment of Standalone VFD with Compressor (C) version in field

1. Change the bearings to insulated type for motors >=90kw at Non Drive End side of Motor

2. Turndown only upto 50% for conversion models (considering the motor speed) i.e. motor frequency range is 50 - 25 Hz for 50Hz variant and 60 - 30Hz for 60Hz variant. No pressure turndown is applicable

3. Run the compressor in the VFD operating range (50 to 25Hz) and skip the frequency in VFD controller (within +/-1Hz) if abnormal noise / vibration is observed

4. Change the thermal element from 65°C to 75°C



		ш —					D					പ							Ш			_				∢	<b>,</b>		_
-	TY/REGULATORY) TT/FORM/FUNCTION/FINISH)		AIR FILTER	CHDKE INDICATOR	INTAKE VALVE (NC)	AIR END	air - Cil Seperator Tank	AIR-DIL SEPERATOR	ndnimam pressure Valve	AFTER COOLER	SAFETY VALVE	THERMAL VALVE	atl cooler	oll filter	1	dil dradn valve	BLDV. DDVN VALVE (ND)	solendid valve (nc)			REMARKS		DIMBATORE - INDIA.		RIES			1557 8	REVISION R 0 1
-	I ACTERISTIC (SAFE HARACTERISTIC (FI	UL FGFND		•	₩1 ₩	$\bigcirc$		$\Diamond$		$\diamond$	• <b>`</b> }	Ē	$\diamond$	$\diamondsuit$	$\diamond$	*	Ē	₩ <u></u>			Nol Rev.				AWING-EG SE	C AND CV	NEXT ASSY.	01 53	ET 2 JF 2
ç	- CRITICAL CHAR - SIGNIFICANT CH		101	102	103	104	105	106	107	108	109	110	111	aı	113	114	115	91			Qtv. DRAWING				GA DR/	0	-	DRG.No.	DRG.SHE
-				Compressed Air	Discharge	E											100 1				CRIPTION	.22 (USA & BRAZIL				TE	.16 REF.DRG.No.	17 SCALE	+     _1.
c	n	П			<u> </u>	Condensate drai							Г				, ) ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		7		DESC	i EG 11.15.18	i	KIAL -	÷	NAME DA	KVV 22.09.	ED SS 23.01.	ED PMU 23.01.
		To Controller	5 55	$\frac{1}{1}$									Ţ		8	✓		┎╉			SI.No	ACM		MALE	WEIGI		CAD	СНЕСКЕ	CHKD.BY APPROV
		ļ							_◄-		-4			$\geq$			<b>⊕</b> −											-	ALT. BY
	Ŧ	& I DRAWING					-4		•				$\supset$			→ )→		•											z
		പ			To Controller					Driftce	Savending				!	8	≞ □					7	I RANGE	0-150° C	e 4 - 16 bar	ve 220 V AC - NC			DESCRIPTIO
u	n		¢ G	SI 1	ļŢ				E	E	To Controller	12 OF					PIPE SIZE	1 inch	1/4 inch	3/4 inch	2 inch		N LOCATION	SENSOR After Air end	ISOR After moistur separator	VE (NC) on intake val		-	
	-		Ŷ			¥	113 check Valv	A Suction of throattle (NC)	Q	Ð							EGEND	- Air Line	- Pulse Line	Oil Line			DESCRIPTIO	TEMPERATURE	PRESSURE SEN	SOLENOID VALV		-	. DATE
					0			]															INSTRUMENT TAG NO	TS01	PS01	116		ŀ	ECO.No
		ری (میر <mark>ا</mark>	<u>ca</u> 1 70	¢			لمر <u>اسحا اسم</u>	<b>N</b> U 303	.T	I -					-1		יחרכגא												REV. NO.
	ı ⊿ı2		6N 8N	91 2N	NA NO NA NO NICH 2.4WRDT		2N IN	NTILE BU Dichne22 2,5,WBDF Dichne22	13 1000 13	<b>4</b> 000	200 5000 2 1000 w)	312 100 150 31	150 30	9 30 - 9 36 Defin 1	- - -	nice Brincp: Ting de∧i	ng to 1 DVER Machin	DIMN.				anc <u>ATIAL</u> 9ne	à pe qi <u>: :DNEIDE</u>	boux. niq oul "IMITED "IMITED "IMITED "IMITEK"	pre com docurs for docurs UNLE22	i ninchi zintini flugi f flugi flugi flugi flugi f f f flugi f f f	S AKE 1 of ELI Shese ir Sermiss	unkusuux property ction of † ction of t	nofini JIA ant bra uborges ant dfiw

# 4.0 Technical data



## Standard, Standard + VFD

Mode		-		EG	11		EG 15					EG	18		EG 22			
Working pre	ssure	psi.g	100	125	150	175	100	125	150	175	100	125	150	175	100	125	150	175
FAD - Free air		cfm	70	62	55	49	91	84	77	69	116	107	91	80	140	132	112	95
Delivery		m³/ min	1.98	1.76	1.56	1.39	2.58	2.38	2.18	1.95	3.28	3.03	2.58	2.27	3.96	3.74	3.17	2.69
Unloading pre	ssure	psi.g	107	132	157	182	107	132	157	182	107	132	157	182	107	132	157	182
Nominal power	supply	_		208-230V / 460V (+/-10%), 60Hz(+/-5%),3phase														
Main motor rat	hp		15 20 25								3	30						
Type of motors drive & fan driv	(main e)	-	Squirrel Cage Induction-TEFC & Cooling Fan Integrated Motor															
Insulation and		_		Class F & IP55														
protection of m	ain motor																	
Frame size / mo type	ounting	-	254T/L / B35 256T / B35 284T / B35 286T /								/ B35							
Type of starter	STD								Auto	matic	Star I	Delta						
for main motor	STD + VFD	-						Throu	ugh Va	ariable	e Frequ	lency	Drive					
Maximum fan n rating per fan X fans	hp	0.35 0.39	5 (20) 9 (460	8-230' V) X 1	V) / Fan			0.3	5 (20	)8-230	) / (V)	0.39 (	460V)	X 2 F	ans			
Rated speed of motor	rpm						1490	(208)	V-230	V) / 1	560 (4	460V)						
Safety valve se pressure	psi.g	205																

# 5.0 Installation and operation

E	L	
	 _	_

Contents	Page No.
5.1. Installation and commissioning	5.2
5.1.1 Unpacking	5.2
5.1.2 Disposal of packing materials	5.2
5.1.3 Handling the compressor	5.2
5.1.4 Site requirements	5.2
5.1.4.1 Ventilation	5.3
5.1.5 Electricals	5.4
5.1.6 Air pipe dimensions	5.5
5.1.7 Receivers for compressed air systems	5.7
5.1.8 Possible mistakes	5.7
5.1.9 Commissioning procedure	5.7
5.1.10 Oil fill procedure	5.8
5.2. Preservation for long idle storage	5.9
5.2.1 Airend	5.9
5.2.2 Motor	5.9
5.2.3 Air-oil separator tank	5.9
5.2.4 Rubber hoses	5.9
5.3. Operating instructions	5.10
5.3.1 Initial start-up checks	5.10
5.3.2 Initial start-up	5.10
5.3.3 Pre-start checks	5.10
5.3.4 Starting	5.10
5.3.5 During running	5.10
5.3.6 Stopping	5.11
5.3.7 Changing the compressor settings	5.11

## 5.1 Installation and commissioning

ELGi

Before the new EG series compressor is operated for the first time, it needs to be installed at your site according to ELGi's installation guidelines.

## 5.1.1 Unpacking

Unpack the compressor from the packing case by removing the nails. Unscrew the bolts, holding the compressor to the base of the crate.

Once the packing material is removed, check the contents against the packing list. The compressor is shipped with the following

- Key for doors
- Operation and maintenance manual
- Checklist of parts of the machine
- Electrical drawing

## 5.1.2 Disposal of packing material

The wood/cardboard used to make the shipping crates of the EG series compressors are biodegradable.

The polyethylene covers wrapped around the compressor and the polystyrene packing provided around the electrical panels are not recyclable. They must be disposed off in accordance with prevailing local environmental laws.

## 5.1.3 Handling

- 1. Lift compressors using either a forklift/pallet truck (Fig.2) or a crane (Fig.3).
- When using a forklift, ensure padding is used in between the compressor and forklift (as shown in Fig.2) to prevent damage to the compressor's canopy.
- 3. When using a crane, please ensure stiff spreader bars are used (as shown in Fig.3) to prevent rope slings from damaging the compressor's canopy.
- 4. Do not drop the compressor.
- 5. Do not attempt to move the compressor by pushing or dragging it as this may cause jerky movements causing damage to the compressor.





Figure 3. Lifting using crane

#### NOTE

#### Removal of transit brackets:

Once you have placed the compressor in its final position, remove the red painted transit brackets and store for future use.

#### Locations:

- Bracket in between the base and airend support
- Bracket in between the base and motor
- Bracket in between the shroud and control panel box

## 5.1.4 Site requirements

- Install the air compressor in a clean, dry, cool and dust free room as extreme temperatures (hot or cold), moisture, air borne contaminants can significantly affect compressor performance, durability and compressed air quality.
- Be aware the entrance to the compressor room should be high enough and wide enough to carry the compressor in and out.
- Leave a minimum of 1m (3.28ft) space around the compressor for safe and proper inspection, cleaning, and maintenance activities.
- Leave minimum of 2m (6.56ft) space above the compressor for hot air to flow away from the compressor.
- Ensure the compressor is protected against direct sunlight and rain.
- Avoid exposing the compressor to excessive moisture (from rain, dryer vent, etc.) as moisture can affect airend lubrication, promote rust formation on the compressor and lead to electrical problems of the motor.
- Neither install the machine in a location where flame is used nor place any inflammable objects near the compressor.



- Ensure the room temperature is within 50°C (122°F) as high ambient temperatures can reduced oil life due to higher discharge oil temperature (DOT). It also results in high approach temperatures affecting cooling and condensation efficiency in the after-cooler and in air treatment equipment like air dryers.
- Ensure the hot medium of other utility equipments like genset/dryer/ boilers, etc., hot medium not sucked by compressor inlet or that in any way room temperature does not rise to prevent high discharge oil temperature.
- Ensure the ambient temperature does not drop below 0°C (32°F). Provide air supply openings and adjustable louvers to ensure that the minimum temperature does not drop down below 0°C (32°F).
- Ensure unevenness of the surface is within 6mm (0.25").



Figure 4. Vertical clearance around the compressor



MINIMUM CLEARANCE, X=1 m (3.5 ft)

#### Figure 5. Horizontal clearance around the compressor

- If the floor is splashed frequently with water while cleaning, then place your compressor on a raised concrete plinth 100 to 150 mm (4 to 6 inches) high.
- Ensure the compressor base makes 100% contact directly with the floor.
- Know that an industrial floor with level surface capable of supporting the weight if the compressor is sufficient

for installing your compressor. No special foundation or anchoring is necessary for rotary screw compressors.

- Do not store toxic, volatile, or corrosive agents near the compressor.
- Isolate the compressor from corrosive agents like ammonia, chlorine, salt spray, and other chemicals as these may erode the internal components and also contaminate the oil and filters.
- Do not allow hot air from additional equipment to blow towards the compressor.
- If you operate in high dust applications like rice mills, cement, flour mills, etc., it would be necessary to clean and replace the filters more often.
- Good practice is to have overhead lifting in the compressor room to facilitate any major overhaul. If an overhead hoist is not available, you should be able to use a mobile crane or forklift truck in your compressor room at a minimum.

## 5.1.4.1 Ventilation

- A part of electric energy to your compressor motor is converted into heat and this heat must be removed from the compressor room by suitable ventilation.
- The ventilation requirements of the compressor are listed in Table 1.
- The ventilation requirements could be achieved by the following methods.
- Natural ventilation is sufficient if the temperature rise in the compressor room (measured by a thermometer near the air inlet pre-filter) is within 5°C (9°F) when compared with outside temperature
- Forced ventilation with an exhaust fan is necessary if the temperature rise inside the room (measured by a thermometer near the air inlet pre-filter mesh) is rises above  $5^{\circ}C(9^{\circ}F)$ .
- Ventilation with ducts: Ensure hot air exhaust from the compressor is diverted through the ducts when installed in an enclosed area. (contact ELGi for ducting requirements)
- Provide openings on walls/partitions close to the air suction side of the compressor.
- Provide exhaust openings close to the ceiling for hot air exit.
- If more than four compressors are installed in a room, good practice is to provide ducting arrangements. This will avoid hot air recirculation.
- Be aware hot air recirculation in the enclosed area will affect the compressor performance.
- Ensure the air velocity in the supply and exhaust ducts does not exceed 4 m/s (13 ft/s).
- Know air velocity is ascertained during commissioning

using an anemometer.

• Do not connect cool air inlet ducts directly to the compressor inlet side.

Model	Minimum ventilation requirement (ft <sup>3</sup> /h)	Minimum ventilation requirement (m <sup>3</sup> /h)				
EG 11	94,537	2,677				
EG 15	128,086	3,627				
EG 18	157,185	4,451				
EG 22	204,154	5,781				
EG 30	242,576	6,869				
EG 37	299,185	8,472				
EG 45	363,847	10,303				
EG 55	464,246	13,146				
EG 75	631,708	17,888				
EG 90	705,481	19,977				
EG 110	864,821	24,489				
EG 132	1,033,801	29,274				
EG 160	1,273,482	36,061				
EG 200	1,718,976	48, 676				
EG 250	1,718,976	48, 676				
EG 90-P	708,765	20,070				
EG 110-P	1,218,356	34,500				
EG 132-P	1,218,356	34,500				
EG 160-P	1,218,356	34,500				

Table 1. Global series – Ventilation requirements

- To eliminate transmission of vibrations, provide a soft bellows connector between the duct and the compressor.
- Contact ELGi in case you need to provide a duct connection or filter fitment on the compressor.

## 5.1.5 Electricals



Figure 6. Forced ventilation with exhaust fan



Figure 7. Ventilation with ducts

## 

Ensure that only authorized service technicians perform electrical work. Study the electrical circuit diagram before starting work.

Madal	Motor power		Back up fuse		Incomir si	ng Cable ze	Incoming	Cable size	Earth cable	Gland Size
Model	kW	H.P	208 - 230V	460V	Cu Sq.mm	Al Sq.mm	Cu Sq.mm	Al Sq.mm	Size	Dia
EG 11	11	15	100A	63A	4 X 10	4 X 16	4 X 4	4 X 6	2.5 Gauge	25 mm
EG 15	15	20	100A	63A	4 X 16	4 X 25	4 X 6	4 X 10	2.5 Gauge	25 mm
EG 18	18	25	125A	63A	4 X 25	4 X 35	4 X 6	4 X 10	2.5 Gauge	25 mm
EG 22	22	30	160A	63A	4 X 35	4 X 50	4 X 10	4 X 16	4 Gauge	28 mm
EG 30	30	40	200A	100A	4 X 50	4 X 70	4 X 16	3 1/2 X 25	4 Gauge	32 mm
EG 37	37	50	250A	125A	4 X 70	4 X 95	3 1/2 X 25	3 1/2 X 35	6 Gauge	35 mm
EG 45	45	60		125A			3 1/2 X 35	3 1/2 X 50	6 Gauge	35 mm
EG 55	55	75		160A			3 1/2 X 35	3 1/2 X 50	6 Gauge	35 mm
EG 75	75	101		250A			3 1/2 X 70	3 1/2 X 95	8 Gauge	50 mm
EG 90	90	121		250A			3 1/2 X 70	3 1/2 X 95	8 Gauge	50 mm
EG 110	110	147		315A			3 1/2 X 95	3 1/2 X 120	25 x 3 cu flat	1.75 inch
EG 160	160	214		400A			3 1/2 X 150	3 1/2 X 185	35 x 3 cu flat	2.25 inch

 Table 2. Global series – Electrical requirements

- 1. Supply power to the compressor through a dedicated switch disconnected fuse (SDF) unit of a suitable rating mounted within 5 m (16.4ft) of the compressor. (This architecture lets you isolate the compressor).
- 2. Use HRC (high rupturing current) fuse instead of an MCCB (moulded case circuit breaker) to avoid possible contactor and motor failure.
- 3. Refer to Table 2 for fuse and cable specifications for 208 -230/380/440/460 V, 60Hz, 3-Ph power supplies.
- 4. Do not use an MCB (miniature circuit breaker) because the selection of contactors is based on Type-2 coordination.
- 5. Connect the earthling line to the point provided on the base frame at the side of the compressor and motor.



Figure 8. Earthing line of compressor

					NPS Pipe	size/ Ins	ide diamet	er (mm)				
Volume F	low FAD	1,	/2	3,	/4		1	1	1/4	1 1/2		
		15	.80	20	.93	26	6.65	35	5.05	40	.89	
(m <sup>3</sup> /min)	(cfm)	(bar)	(psi)	(bar)	(psi)	(bar)	(psi)	(bar)	(psi)	(bar)	(psi)	
0.1	4	0.02	0.22									
0.2	7	0.06	0.80	0.01	0.20							
0.3	11	0.12	1.69	0.03	0.41	0.01	0.12					
0.4	14	0.20	2.88	0.05	0.71	0.01	0.21					
0.5	18	0.30	4.35	0.07	1.07	0.01	0.32	0.01	0.08			
0.6	21	0.43	6.09	0.10	1.49	0.03	0.45	0.01	0.11			
0.7	25	0.57	8.10	0.14	1.99	0.04	0.59	0.01	0.15			
0.8	28	0.73	10.38	0.18	2.54	0.05	0.76	0.01	0.19	0.01	0.09	
0.9	32	0.90	12.90	0.22	3.16	0.07	0.95	0.02	0.24	0.01	0.11	
1.0	35	1.10	15.68	0.27	3.84	0.08	1.15	0.02	0.29	0.01	0.13	
1.2	42			0.38	5.38	0.11	1.61	0.03	0.41	0.01	0.19	
1.4	49			0.50	7.16	0.15	2.14	0.04	0.54	0.02	0.25	
1.6	56			0.64	9.16	0.19	2.74	0.05	0.70	0.02	0.32	
1.8	64			0.80	11.40	0.24	3.41	0.06	0.87	0.03	0.40	
2.0	71			0.97	13.85	0.29	4.14	0.07	1.05	0.03	0.49	
2.2	78			1.16	16.52	0.35	4.94	0.09	1.25	0.04	0.58	
2.4	85			1.36	19.40	0.41	5.80	0.10	1.47	0.05	0.68	
2.6	92					0.47	6.73	0.12	1.71	0.06	0.79	
2.8	99					0.54	7.72	0.14	1.96	0.06	0.91	
3.0	106					0.61	8.77	0.16	2.23	0.07	1.03	
3.5	124					0.82	11.66	0.21	2.96	0.10	1.37	
4.0	141					1.05	14.93	0.27	3.79	0.12	1.75	
4.5	159					1.30	18.57	0.33	4.71	0.15	2.18	
5.0	177							0.40	5.73	0.19	2.65	
5.5	194							0.48	6.83	0.22	3.16	
6.0	212							0.56	8.02	0.26	3.71	
6.5	229							0.65	9.30	0.30	4.30	
7.0	247							0.75	10.67	0.35	4.94	
7.5	265							0.85	12.12	0.39	5.61	
8.0	282							0.96	13.66	0.44	6.32	
8.5	300							1.07	15.28	0.50	7.07	
9.0	318							1.19	16.99	0.55	7.86	
9.5	335							1.32	18.477	0.61	8.69	
10.0	353							1.45	20.64	0.67	9.55	
15.0	530									1.42	20.22	

## 5.1.6 Air pipe dimensions

					NPS Pipe	size/ Ins	ide diame	ter (mm)					
Volume F	low FAD	1 1	l/ <b>2</b>		2	2 :	1/2		3		4		
		40	.89	52	.50	62	.71	77	.93	102	2.26		
(m³/ min)	(cfm)	(bar)	(psi)	(bar)	(psi)	(bar)	(psi)	(bar)	(psi)	(bar)	(psi)		
0.8	28	0.01	0.09										
0.9	32	0.01	0.11										
1.0	35	0.01	0.13										
1.2	42	0.01	0.19										
1.4	49	0.02	0.25	0.01	0.07								
1.6	56	0.02	0.32	0.01	0.09								
1.8	64	0.03	0.40	0.01	0.11								
2.0	71	0.03	0.49	0.01	0.14								
2.2	78	0.04	0.58	0.01	0.17								
2.4	85	0.05	0.68	0.01	0.20	0.01	0.08						
2.6	92	0.06	0.79	0.02	0.23	0.01	0.09						
2.8	99	0.06	0.91	0.02	0.26	0.01	0.11						
3.0	106	0.07	1.03	0.02	0.30	0.01	0.12						
3.5	124	0.10	1.37	0.03	0.39	0.01	0.16						
4.0	141	0.12	1.75	0.04	0.50	0.01	0.21						
4.5	159	0.15	2.18	0.04	0.63	0.02	0.26	0.01	0.09				
5.0	177	0.19	2.65	0.05	0.76	0.02	0.31	0.01	0.11				
5.5	194	0.22	3.16	0.06	0.91	0.03	0.37	0.01	0.13				
6.0	212	0.26	3.71	0.07	1.06	0.03	0.44	0.01	0.15				
6.5	229	0.30	4.30	0.09	1.23	0.04	0.51	0.01	0.17				
7.0	247	0.35	4.94	0.10	1.42	0.04	0.58	0.01	0.20				
7.5	265	0.39	5.61	0.11	1.61	0.05	0.66	0.02	0.22				
8.0	282	0.44	6.32	0.13	1.81	0.05	0.75	0.02	0.25				
8.5	300	0.50	7.07	0.14	2.03	0.06	0.83	0.02	0.28	0.01	0.07		
9.0	318	0.55	7.86	0.16	2.25	0.06	0.93	0.02	0.31	0.01	0.08		
9.5	335	0.61	8.69	0.17	2.49	0.07	1.02	0.02	0.35	0.01	0.09		
10.0	353	0.67	9.55	0.19	2.74	0.08	1.13	0.03	0.38	0.01	0.10		
15.0	530	1.42	20.22	0.41	5.80	0.17	2.38	0.06	0.80	0.01	0.21		
20.0	706			0.69	9.87	0.28	4.06	0.10	1.37	0.02	0.35		
25.0	883			1.05	14.92	0.43	6.13	0.15	2.07	0.04	0.53		
30.0	1059			1.46	20.90	0.60	8.59	0.20	2.90	0.05	0.75		
35.0	1236					0.80	11.43	0.27	3.86	0.07	0.99		
40.0	1412					1.03	14.63	0.35	4.94	0.09	1.27		
45.0	1589					1.28	18.20	0.43	6.14	0.11	1.58		
50.0	1765							0.52	7.46	0.13	1.92		
55.0	1942							0.62	8.90	0.16	2.29		
60.0	2118							0.73	10.46	0.19	2.69		
65.0	2295							0.85	12.13	0.22	3.12		
70.0	2471							0.97	13.91	0.25	3.57		
75.0	2648							1.11	15.80	0.28	4.06		
80.0	2824							1.25	17.81	0.32	4.58		
85.0	3001							1.40	19.92	0.36	5.12		
90.0	3177									0.40	5.69		
95.0	3354									0.44	6.29		
100.0	3530									0.48	6.92		
150.0	5295									1.03	14.64		

#### Table 3. Global series – Air pipeline dimensions

## NOTE

The above table shows the pressure drops in 100m length schedule 40 steel pipe at 7 bar (abs)

2. In case the main delivery pipe is more than 100 m (330 feet) long, use a pipe diameter that is one size bigger than shown in the table.

<sup>1.</sup> Use the pipe sizes (as in Table 3) for the delivery pipe that connects to ball valve of the compressor.

## 5.1.7 Receivers for compressed air

## systems

Receiv applicat	ver tions	Compressed capacity										
	Volume	On	/Off control	Modulation control								
m <sup>3</sup>	ft <sup>3</sup>	m <sup>3/</sup> min	cfm	m <sup>3/</sup> min	cfm							
0.3	10.59	Up to 1.13	Up to 40	Up to 1.7	Up to 60							
0.5	17.66	1.14 - 2.4	41 - 85	1.7 - 3.4	61 - 120							
1.0	35.32	2.4 - 4.0	86 - 140	3.4 - 6.7	121 - 235							
1.5	52.97	4.0 - 6.4	141 - 225	6.7 - 10.0	236 - 355							
2.0	70.63	6.4 - 8.8	226 - 310	10.0 - 13.0	356 - 470							
3.0	106.0	8.8 - 12.6	311 - 445	13.0 - 20.1	471 - 710							
4.0	141.3	12.6 - 16.1	446 - 570	20.1 - 26.7	711 - 945							
5.0	176.6	16.1 - 19.8	571 - 700	26.7 - 33.4	946 - 1180							
6.0	211.9	19.8 - 24.0	701 - 850	33.4 - 40.0	1181 - 1415							
7.0	247.2	24.0 - 28.0	851 - 990	40.0 - 46.7	1416 - 1650							
8.0 282.5		28.0 - 32.0	990 - 1130	46.7 - 53.3	1651 - 1885							

Table 4. Global series-Receivers specifications

## 5.1.8 Possible mistakes

- 1. The compressor is installed on the wooden pallet of the packing case.
- 2. The compressor base is not making 100% contact with the floor.
- 3. The compressor is mounted on anti-vibration mounts.
- 4. The isolator is more than 5m (16.40ft) away from the compressor.

## 5.1.9 Commissioning procedure

- 1. Please make preparations according to the installation section as given, before the compressor is commissioned.
- 2. Ensure that the location meets the requirements of accessibility, ventilation and safety.
- 3. Provide electrical power as recommended in the installation section.
- 4. Select air pipe lines and receivers for your system according to the tables provided in the installation section.

## **Checkpoints before commissioning**

Replace the parts in compressor if it had been in storage for more than one year.

- 1. Air filter
- 2. Oil filter
- 3. Air oil separator (check and replace)
- 4. Oil
- a. Check for any external / internal damages of the package.
- b. Monger the main motor and fan motor should be mongered to find the winding insulation conditions if the compressor is not commissioned for more than 1 year

- c. Re-grease the main motor if the compressor is not commissioned for more than 1- 1/2 years (18 months)
- d. Replace the AVMs if you detect any abnormal squeezing or damage in the rubber part.
- e. Check whether all the screws in the control panel are in place and tightened properly.
- f. Check the oil cooler and after-cooler for any external fin blockage and clear the blockage if necessary
- g. Ensure that all the transit brackets are removed.

## **During commissioning**

The servicing technician performs a series of checks on the machine and on the systems to which it connects, to ensure that it is in a condition to function safely and as recommended. The servicing technician will then explain to the operate and maintain the equipment. This procedure is referred to as the commissioning process.

The commissioning of the compressor ensures that it is installed safely.

The general operating conditions of the equipment including the cleanliness of the atmosphere, the temperature and the ventilation are checked. Technical details relating to your system such as particulars of your electrical installation are noted. The operator of the compressor is familiarized with all aspects of both its normal running and dealing with unusual situations.

Upon completion of the commissioning process, the technician will fill in the document known as the commissioning report and the warranty card provided in this manual.

During commissioning any modification suggested by the technician should be performed before the compressor is ready for regular use. Else, warranty becomes void. In case of change of operator other than the person trained, the new operator should be trained before he is dedicated for operating the compressor.

## 5.1.10 Oil fill procedure

## Initial oil fill procedure

Check whether your compressor comes with oil filled. This can be checked through the oil sight glass on the air oil separator. If not, follow the oil filling procedure given below.



#### Figure 9. Oil filling and oil sight glass location on air oil seperator tank

## **Oil level check**

- The oil level should be half of the oil sight glass after fumes settle down following shutdown.
- Ensure that the oil level sight glass and eye vision are parallel while checking the oil level to avoid parallax error.

SI. No.	Model	Volume of oil required (gallons)
1	EG 11, 15	2.9
2	EG 18, 22	3.7

## NOTE

Refill oil in the tank if the level falls below the minimum level



## 5.2 Preservation for long idle storage

If your compressor is going to remain unused for six months or longer, special measures must be undertaken to ensure the protection of the following components

- Airend
- Motors
- Air-oil separator tank
- Rubber hoses

## 5.2.1 Airend

To prepare the airend for 6-month storage:

- Remove the airend discharge hose/pipe coupling.
- Rotate the drive coupling three times so that the oil present inside the airend comes out through the discharge port.
- Block the discharge port completely.
- Remove the inlet rubber duct connected to the intake valve of the air filter assembly.
- Turn the intake valve flap and pour rust preventive oil (use Castrol DWX 32 or an equivalent grade) into the airend through the intake valve.
- Rotate the coupling five times by hand so that the rust preventive oil spreads all over the bearings, seals and other parts of the airend.
- Drain the rust-preventive oil by opening the discharge port plug fully.
- Refit the hose/pipe coupling on the discharge port.
- Take care to ensure that all the openings are plugged always to avoid dust entry.
- Rotate the compressor shaft once in 7 days and ensure free rotation.
- Repeat the procedure every six months.
- For more details contact ELGi office or distributer network.

## 5.2.2 Motor

To prepare the motor for 1-year storage:

- Check the insulation of the motor winding.
- Remove any moisture in the motor.
- Check junction box terminals for tightness of the wires.
- Apply grease on the motor bearings.

## 5.2.3 Air-oil separator tank

To prepare the air-oil separator for 2-year storage:

- Drain the oil from the seperator tank.
- Remove the entire tank from the compressor after disconnecting it from all hoses, the tank top plate, the minimum pressure valve outlet line, and control pulse lines and control switches.
- Clean the tank using ELGi compressor clean flushing oil.

- Check the air-oil separator tank.
- Replace the oil filter element similarly.
- Flush the tank, airend with compressor oil and replace the separator element before using the compressor again.

ELGi

## 5.2.4 Rubber Hoses

Test Recommendations for		
Age Recommendations		
Up to 3	Use without further testing	
3 to 5 years	Use after representative samples are	
5 to 8 years	Use after representative samples are subjected to proof, impulse, and burst pressure tests and cold bend and	
Over 8 years Scrap		



## 

*Please adhere to the safety instructions provided at the section 2.3.2 : Precautions during operations* 

## 5.3.1 Initial start-up checks

- Check whether the oil level in the tank is up to the specified level. If not, top up oil as per the oil fill procedure given in the maintenance section.
- Open all doors and visually check the compressor for abnormality. Make sure all connections are tight.
- Open the electrical panel door of the compressor and check that the three phases and earth cables are connected securely. (L1, L2, L3, and PE wires)
- Check the necessary earthing line in the panel/ compressor base.
- Ensure that all condensate drains are connected properly.
- For water cooled compressors, ensure that the water inlet and outlet valves are opened. Also make sure that the inlet and outlet water drain valves are closed.
- For water cooled compressors, ensure that the water quality is maintained as specified by ELGi.

## 5.3.2 Initial start-up

Open the air outlet ball valve, turn on power, and press the start button (Green). Check whether the main motor turns clockwise (when viewed from the main motor fan side of the compressor). The correct direction of rotation is also shown on the motor. Ensure correct direction of rotation. If not, stop the compressor by pressing the stop button (Red) on the control panel. Open the isolating switch and reverse the appropriate lines.

## **WARNING**

Running the compressor in the wrong direction for more than 5 seconds will damage compressor parts or even cause total damage.



#### Gear models

EG 11 - All pressures

EG 15 - All pressures

EG 18 - 150, 175

EG 22 - 175

## 5.3.3 Daily start checks

Before using the compressor everyday, you must prepare it by performing these tasks:

- Check whether the oil level in the tank is up to the specified level. If not, top up oil as per the oil fill procedure given in the maintenance section.
- Open all doors and visually check the compressor for abnormality. Make sure all connections are tight.
- Refer section 6.1.1 for how to perform daily maintenance activities.

## 5.3.4 Starting

To prepare to start the system, perform these tasks:

- Open the air discharge valve.
- Turn on power.
- If all the inputs from contact switches, pressure and temperature transducers are normal, the display will indicate "READY".
- Press the "START" (green) button on the controller.
- Machines with an automatic star-delta starter will have 6 seconds changeover time from star to delta and another 10-seconds delta-to-run delay.

## 5.3.5 During running

To ensure seamless running:

- Monitor the controller display and control panel indicators regularly when the compressor is running.
- **Graphic warning display:** This gives graphically the location of fault.

#### GRAPHIC WARNING DISPLAY



#### Figure 10. Human machine interface

- Discharge temperature sensor & warning: It is fixed on the air-oil discharge pipe. It senses the temperature of the discharge air-oil mixture. The compressor will shutdown automatically and the warning light on the controller will glow when the discharge temperature exceeds the preset value of 110  $\pm$  5°C (230  $\pm$  9°F).
- Separator element warning: Indicates that the separator element needs to be replaced. The compressor will not shutdown automatically in this situation.

Installation and operation

- **Oil filter warning:** Indicates that the oil filter element needs to be replaced. The compressor will not shutdown automatically in this situation.
- High discharge temperature warning: The compressor will shutdown automatically and the warning light on the controller will glow when the discharge temperature exceeds the preset value of 110  $\pm$  5°C (230  $\pm$  9°F).
- Main motor overload trip: The compressor will shutdown when the main motor is overloaded and the corresponding warning light will glow.
- Fan motor overload trip: The fan motor has internal thermal overload protection, which safeguards the fan motor. If the fan motor trips discharge oil temperature will be high and the compressor will trip.
- **Reset button:** This button must be pressed before restarting the compressor after it has shutdown with a warning. The machine must be restarted only after taking necessary remedial measures.
- Safety valve: This valve relieves the pressure in the air -oil separator tank when it exceeds the set pressure. Refer "Technical data".
- **Reverse direction switch:** If the motor rotates in the wrong direction, the reverse direction switch detects and, in turn, trips off the compressor.
- After reaching the maximum cutoff pressure the pressure sensor senses the pressure and cuts off the solenoid electrical supply.

Model	Туре	Cutout pressure bar (psi)
EG 11 - EG 45	Standard, Standard +VFD	Working pressure + 0.5 (7)
EG 55 -	Standard	Working pressure + 1 (15)
EG 160	Standard +VFD	Working pressure + 0.5 (7)

## 5.3.6 Stopping

- Press the stop (Red) button in the controller. The compressor will come to a halt within 10 seconds.
- In case of emergency, to stop the compressor, use the emergency stop switch. Correct the fault, rotate counterclockwise and unlock the emergency switch. Then press the reset button before the next start.
- Do not use the emergency stop switch for normal stopping.
- Isolate power to the compressor.
- Close the air discharge valve.
- For water cooled models, close the water inlet valve.
- If there is any possibility of freezing exists, drain the cooling system completely.

## 5.3.7 Changing the compressor settings

Change the compressor settings using the tactile keypad and LCD panel on the controller. (Refer to Neuron manual to learn more about the control panel and how to interpret of the message.)

Refer the VFD setting procedure manual for VFD operations.

## 

- Isolate power supply before the discharge ball valve closes.
- Do not use the emergency stop switch for normal stopping

Contents	Page No.
6.1. Maintenance	6.2
6.1.1 Maintenance intervals	6.2
6.1.2 Maintenance of individual components & systems	6.3
6.1.2.1 Pre filter	6.3
6.1.2.2 Air filter	6.3
6.1.2.3 Air oil Separator	6.4
6.1.2.4 Oil top up and oil changeover	6.5
6.1.2.5 Oil filter	6.5
6.1.2.6 Intake valve	6.6
6.1.2.7 Blow down valve	6.8
6.1.2.8 Minimum pressure valve	6.8
6.1.2.19 Thermal valve	6.9
6.1.2.10 Electrical motor greasing	6.9
6.1.2.11 After and oil coolers	6.9
6.1.2.12 Cooler prefilter accessory	6.9
6.1.2.13 Drive coupling	6.10
6.1.2.14 Moisture separator and auto drain valve	6.10
6.1.3 Use only genuine spare parts	6.12
6.2. Troubleshooting	6.13
6.3. Decommissioning, dismantling & putting out of service	6.18
6.3.1 Waste disposal	6.18
6.3.2 Dismantling the compressor	6.18
6.3.3 Decommissioning the compressor	6.18
6.3.4 Disposal of consumables and replaced parts	6.18
6.4. ELGi services	6.19
6.4.1 ELGi customer care system (ECCS)	6.19
6.4.2 ELGi genuine spare parts	6.19
6.4.3 Air audit	6.19
6.5. Appendix	6.21
6.5.1 Conversion tables	6.21
6.5.2 Torque values	6.22
6.5.3 Service log book	6.23
6.6. Disclaimers	6.24





## 6.1.1 Maintenance intervals

Frequency	Part	Remarks	
	Oil level	Check	
Daily	MOS condensate	Check	
Dally	Warning / alarms	Check	
	Condensate in AOS tank	Check	
Weekly	Pre filter ( air intake, cooler, control panel)	Clean	
Weekiy	Air filter element	Clean *	
	Oil & after coolers - air cooled (External)	Check & Clean	
2000 hours	Oil filter	Replace	
2000 hours	Oil	Sampling **	
	50 Hz motor - 2 pole grease	Replace	
	Pre filter ( air intake, cooler, control panel)	Replace	
	Air filter element	Replace	
	Oil – Air lube XD / Air lube FG	Replace	
	Air-oil separator element – Air lube XD / Air lube FG	Replace	
4000 hours or every year #	50 Hz motor ( 4 pole ) grease	Replace	
	60 Hz motor ( > 25HP ) grease	Replace	
	Electrical connections	Check	
	Return line sight glass / orifice / NRV	Check & Clean	
	Return line strainer	Check & Clean	
	Air-oil separator element - UT Synthetic	Replace	
	Oil - UT Synthetic	Replace	
	60 Hz motor ( $\leq$ 25HP ) grease	Replace	
	Drive coupling element	Replace	
	Pipe coupling element	Replace	
	Intake valve kit	Replace	
	Actuator kit	Replace	
8000 hours or every 2 years $^{*}$	MPV kit	Replace	
	BDV kit	Replace	
	Solenoid valve	Replace	
	Safety valve	Replace	
	MOS-ADV kit	Replace	
	Control line filter-ADV kit	Check & Replace	
	Nylon tubes	Replace	
	Oil & after coolers - water cooled (External)	Check & Clean	
#- Whichever comes first * - As per air filter clog indicator **- For USA region only			

**Table 5. Maintenance intervals** 

## NOTE

The above life time guidelines are applicable only to standard operating and regular maintenance conditions recommended in this manual. In the event of changes in the conditions, consult ELGi.

## Precautions

#### A. If the compressor is kept idle

- Isolate the power supply.
- Close the main air outlet valve.
- Drain the water from the condensate system.
- Close the inlet and outlet water valve. (applicable only for water cooled compressors)
- B. If the compressor is kept idle for more than 6 months
- Follow the above steps.
- Refer to the section "Preservation for long idle storage".

Volume	ELGi Air Lube UT Synthetic	ELGi Air Lube FG
5 litres (1.3 gallons)	000998067	000998077
20 litres (5.3 gallons)	000998068	000998078
210 litres (55 gallons)	000998069	000998079

#### Table 6. Compressor oil

SI. No.	Motor make	Grease
1	ELGi	ESSO Polyrex EPL
2	SIEMENS	Unirex N3 ESSO
3	WEG	MOBIL Polyrex EM

#### Table 7. Electric motor grease



Disconnect all the power at the source before attempt to perform maintenance or make adjustment.

# 6.1.2 Maintenance of individual components and systems

Check all accessories independently to verify that they are functioning as required and replace their components as necessary. After maintenance restart the compressor as mentioned in section "Operating instructions".

## 6.1.2.1 Pre filter





#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Compressed air, new pre-filter element (if needed)

#### Maintenance

- Switch off the machine.
- Refer to the pre-filter cartridge removal & insert procedure.
- Hold or fix the pre-filter assembly in the cleaning area.
- Clean the pre-filter with compressed air at less than 2.5 bar.g (36.3 psi.g) from the reverse or back side of the pre filter cartridge.
- In case of major dust/dirt accumulation in the pre-filter element, wash with clean water or light detergent.
- Do not use any acidic/alkaline chemicals for cleaning.
- Repeat this process based on dust conditions or at regular periodic intervals.

# Suction pre-filter cartridge removal procedure

#### 1. Slide Upward

Hold the pre-filter between the louvers and

Maintenance

slide upwards slightly until the pre-filter bottom edge is visible

#### 2. Slide Downward

When the pre-filter bottom edge is visible, slant the pre-filter forward and slide it downwards away from the compressor

#### 3. Pull Forward

When the top and bottom edges of the pre-filter are free from the compressor, move the pre-filter forward to remove completely.



# Suction pre filter cartridge insert procedure.

For insert sequence procedure from 3-2-1

## 6.1.2.2 Air filter

If the air filter clog indicator shows a red colour (meaning the blocked condition) then the air filter needs to be cleaned or replaced (if the stipulated life has elapsed).



Figure 12. Air filter

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Compressed air, new filter element (if needed).

#### Maintenance

- Unlock the mounting clips provided on the filter housing.
- Rotate and remove the filter element carefully.
- Clean the filter using moisture free compressed air at less than 2.5 bar.g (36.3 psi.g).
- Clean from the inside to outside.
- Remove the dust ejector from the filter housing cap and clean it carefully.
- Show bright light from inner side of the filter element to inspect for damage or holes that result in leaks. Light



will emerge from the holes, indicating their locations. In case of damages replace the filter element

- Inspect all rubber sealing and their contact surfaces of the housing. Faulty rubber sealing must be replaced immediately.
- Return the dust ejector back in correct (bottom) position.
- Return the filter element back in position, assemble the filter housing cap such that the dust ejector settles in bottom position, and lock the assembly using the mounting clips.
- Inspect and tighten all air inlet connections prior to resuming operation (if necessary).
- Reset the air filter clog indicator.
- If a clean element is to be stored for later use, it must be stored in a clean container.

## 6.1.2.3 Air oil separator

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Strap wrench, new separator element, clean cloth.

#### Maintenance

#### Disassembly of the existing separator:

- Hold the separator outer shell by the removed strap wrench and rotate it counter clockwise, until it completely unscrews.
- Ensure the hex adapter stays in the separator head during disassembly.
- Once the recommended life is over, replace it with a new element.

#### AIR OIL SEPARATOR SHELL



Figure 13. Air oil separator

#### Assembly of a new separator:

- Ensure the O-ring of the separator is damage free.
- Clean the O-ring-seating surface with a clean cloth.
- Apply a thin film of compressor oil on the mating surface of the O-ring.
- Return the separator to its original position and rotate it by hand clockwise.
- Ensure no oil leaks from the mating surface.
- In case of leakage, check the O-ring.
- After tightening by hand, rotate it further for one and a half times.

#### NOTE

The air-oil separator tank is tested according to standards. Regularly have inspections performed in conformity with local regulations.

## 6.1.2.4 Oil top up & oil change over

Proper compressor maintenance and operation is crucial for the lubricant to function properly and last till its estimated rated oil hours. The oil product shelf life is of minimum 3 years and maximum 5 years. Products should be kept properly sealed in the original container. Once the seal is broken, the above stated life span of the product is no longer applicable. Products should be stored in proper storage warehouse that is away from direct sunlight and is not exposed to weather elements like rain, typhoon and snow storms. The products should also be stored away from any heat source, high humidity and moisture areas. If drums are stacked on ground level, they should all be stacked horizontally with the bung openings arranged at the 3 and 9 o'clock position.

ELGi recommends that once the seal is broken, all products be used immediately. ELGi does not encourage reuse or recycling of any leftover fluids due to contamination hazard. ELGi will not warrant the quality of the product once the original seal is broken. Also ensure that the oils are not mixed up between brands and types.

Please refer Material Safety Data Sheet (MSDS) for oil spill handling and disposal procedures.

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• New oil, flushing fluid (if needed)

NOTE

- The compressor is originally filled with a particular oil, if you want to change over to other types of oil, perform steps 1, 2 and 3.
- But if you want to change the oil but continue with the same kind (same brand & type) perform steps 1 and 3 only.
- Ensure that you drain at least 90% of oil capacity of the compressor; if not the residual oil can contaminate new oil.
- Ensure no oil spills on anti-vibration mount during maintenance.

#### Maintenance

#### Step 1: Draining

- a. Remove drain plug from the bottom of the separator tank and drain out all oil. Drain oil while the compressor is warm.
- b. Remove the pipe and drain plug from bottom of oil cooler. Then completely drain.
- c. Disconnect all oil pipe work which could trap oil and drain completely.
- d. Drain oil from the airend discharge pipe after dismantling it.
- e. Drain oil from the airend by hand rotation.

#### Step 2: Flushing (Only for oil change over)

Check the air-oil seperator differential pressure. To flush clean/non-varnished machines, using:

#### Mineral/PAO/PAG oils

- a. Fill the compressor with the ELGi cleaner (use the same compressor oil fill volume) and run the compressor.
- b. After 500 hours of running, drain the cleaner as per step 1.
- c. Refill the compressor with new compressor oil.
- d. Send a sample\*\* of the compressor oil to ELGi for oil analysis after 300 hours.

\*\*: Applicable only for USA.

#### NOTE

- The cleaner is not recommended to run longer than 500 hours.
- Change the oil filter and oil separator after oil change over.

#### Step 3: Filling the oil

- a. Add fresh oil; fill it up to the oil fill plug. (initial fill)
- b. Close the oil fill plug.
- c. Pour oil into airend, then restart the compressor.
- d. Allow it to run for about 10 minutes.
- e. Stop the compressor.

- f. Unscrew the oil filling plug after 5 minutes so that residual pressure in the tank is vented out through the bleed hole in the oil fill plug.
- g. Refill the tank up to the oil fill plug. (second fill)
- h. Restart the compressor.



Figure 14. Air oil separator tank- oil drain



Figure 15. Cooler oil drain

## 6.1.2.5 Oil filter

The oil filter is fitted between the oil cooler and the airend unit. The components of the oil filter assembly are shown in the figure. This is a full flow filter with a pleated element. To service this filter, order the consumables kit (available with ELGi service personnel) The procedure for complete servicing of this filter is as follows.

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool

for a few minutes.

#### Requirements

• Strap wrench, new oil filter, O-ring, and clean cloth.



Figure 16. Oil filter

#### Maintenance

#### Disassembly of the existing oil filter:

- Isolate the machine from the service line, vent separator tank pressure, and allow the tank to cool for a few minutes.
- Hold the filter shell and rotate it counter clockwise using the strap wrench.

#### Assembly of the new oil filter:

- Ensure the O-ring of the filter is damage free.
- Clean the seating surface with clean cotton.
- Apply a thin film of compressor oil on the mating surface of the O-ring.
- Return the filter to its original position and rotate it clockwise manually. After tightening, rotate it further by hand for one and a half times.
- Ensure no oil leaks from the mating surface.

## NOTE

Suspended particulate matter should be less than 150spm to achieve the specified consumable life. Guarantee becomes void if the compressor is operated above its intended pressure.

## 6.1.2.6 Intake valve

## **WARNING**

Valves should not be opened when pressure is applied.

## NOTE

The maintenance of following parts (valves) demands highly skilled authorized personnel. So, it is recommended that an ELGi service engineer does the maintenance.

#### Pre work:

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a 10-minutes.

#### **Requirements :**

• Soft cloth, grease, liquid cleaner, Allen keys, screw driver, spanner, pressure gauge, service kit (if needed).

#### Procedure :

#### **Function of NRV-flaps**

#### **Dismantling:**

• The valve must be completely dismantled from the compressor. Then remove the bearing bolts (4), pin (5), and the NRV-flap..

#### Cleaning:

• Clean the interior of the housing with a liquid cleaner. Wipe any Loctite residue from threads. Seat and sealing areas must by no means be damaged.

#### **Reassembly:**

- Wet a bearing bolt with Loctite 242 and screw it into the thread. Install the NRV-flap or the NRV-flap and counterweight in the housing according to the drawing.
- Press the pin (4) through the bearing bores into the pre -assembled bearing bolt. Wet the second screw with Loctite 242 and screw it in. Lock both screws with 50 Nm (30.87 lb-ft).

#### Function testing:

• Check easy movement of the NRV-flap manually. It must have slight axial play and not touch the housing.

#### 1. Rotary drive unit

- The valve must be completely dismantled from the compressor. (Additionally, the control discs need to be closed by using the pressure air signal as explained before)
- Turn out Tensilock screws (10) and remove the control disc (1) (with a magnet). (Drain pressurized air.).
- Remove the plastic plug (11). Turn out the MHT-nut (15) and remove the 2 rings (13 & 14) below.
- Attention: The spring (6) is pretensioned. When screwing off the cover (8), therefore, press it by hand onto the cover when turning out. Remove the sealing ring (7), piston unit (9), spring (6), rod (12), and the remaining 2 rings (16& 17).

#### **Cleaning:**

• Wipe any residual loctite from the rod (12). Clean the working area of the piston unit (9) with the liquid cleaner and soft cloth. Grease the screw drive of the rod (12) and piston working area with AUTOL TOP 2000.



DETAIL: ROTARY DRIVE UNIT



The flattened medium part of the rod and the thread must be absolutely free of grease. Seat and sealing areas must by no means be damaged.

#### **Reassembly:**

- Insert two discs (16&17) into the housing according to the drawing. The sinter area of the first disc (17) (grey) must point away from the housing in the direction to the second steel disc (16). Turn the piston unit (9) on the rod (12) until it stops. Hold the rod in a way that the flattened part looks upward. Then turn the piston unit back until for the first time a guiding area is parallel with the flattened part of the rod.
- Insert the spring (6) according to the drawing into the housing against spring pressure in a way that the flattened part points to the counterweight section of the housing.
- Block the rod (12). Install two discs (13&14) according to the drawing. The sinter area of the first disc (13)

(grey) must point away from the housing in the direction to the second steel disc (14). Wet the MHT-nut (15) with Loctite 270, lock it, and loosen it again by a 1/6 turn. Insert the sealing ring (7) in the groove provided in the cover (8). Put the cover (8) on top and fix it by turning. Connection E must look downward. Loosen blocking of the rod.

 Install the control disc (1) according to the drawing. The bore for idle operation must always point to the counterweight section of the housing. Wet Tensilock bolts (9) with loctite 270 and lock them. Lock with 9 Nm (6.63 lb-ft). Install the plastic plug according to the drawing.

#### Function testing:

 Connect to pressurized air and test smooth opening/ closing for several times. Adjust by turning the MHT-nut (15) in either direction, if needed. Pay attention to Loctite. If the time is too long, clean Loctite off the nut and wet again .



NOTE

After completion of intake valve assembly in package, ensure to verify the performance

## 6.1.2.7 Blow down valve



#### Figure 18. Blow down valve

#### Pre work

- Switch off the compressor and disconnect power supply to the motor.
- Close the discharge end ball valve.

#### Requirements

• Liquid cleaner.

#### Maintenance

#### **Complete Service and Dismantling**

- Dismantle the valve completely from the compressor.
- Unscrew locking screws (2).
- Remove the piston unit (4) along with the gasket (5)

#### Cleaning

- Work areas and sealing areas of the housing and their threads must be cleaned with the liquid cleaner and any residual Loctite removed.
- Piston work areas have to be greased by any means. Seat and sealing areas must not be damaged.
- Reassembly
- Insert the piston unit (4) into the housing.
- Assemble the gasket (5) cover plate and tighten the locking screws.

#### **Function testing**

• Test the valve function after each service or inspection at the running compressor.

#### Inspection

• Dismantle the valve and check the component for wear.

- Work areas and sealing areas of the housing and their threads must be cleaned with the liquid cleaner and any residual Loctite removed.
- Piston work areas have to be greased by any means. Seat and sealing areas must not be damaged.
- Reassemble the valve as described above and test its functioning.

#### 6.1.2.8 Minimum pressure valve

## **WARNING**

Extreme caution should be taken while removing the cap or cover from the body because of the spring.

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the system to cool for a few minutes.
- Release the receiver tank and downstream pressure.

#### Requirements

• New MPV kit, allen key, grease.



#### Figure 19. Minimum pressure valve

#### Maintenance

#### **MPV Replacement:**

- Isolate the machine from the service line, vent separator tank pressure and allow the system to cool for a few minutes.
- Release the receiver tank and downstream pressure.
- Unscrew the four screws.
- Remove and replace the old MPV kit with a new one.
- Grease the O-ring groove in the new MPV kit.
- Assemble the MPV kit and reinstall the spring and cap.
- Tighten the bolts.
- Adjust stud protrusion (6mm/0.236 inches) to achieve a minimum pressure of 4.5 bar.g (65 psi.g)

#### 6.1.2.9 Thermal valve

#### Pre work

• Switch off the compressor and disconnect power supply



to the compressor.

- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.



Figure 20. Thermal valve

#### Requirements

• Pliers, screw driver, new thermal valve element, new O-ring.

#### Procedure

#### **Replacing thermal Valve**

- Remove the thermal valve element from the thermal valve block body
- Inspect and clean seating area in the housing
- Replace with a new thermal valve.

## 6.1.2.10 Electric motor greasing

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Recommended grease, cleaning cloth, grease gun.

#### Procedure

- Stop the motor and lock out the switch.
- Thoroughly clean the grease inlet fitting or plug. If the motor has a plug, remove the plug and clean the inlet.
- Remove the drain plug and wipe out any hardened grease.
- Slowly pump the grease into the grease inlet until the new grease comes out of the drain plug.
- Start the motor and let it run for a minimum of one hour to expel any excess grease from the drain opening before re-installing the drain plug.
- Stop the motor and lock out the switch.
- Re-install the drain plug.

• Put the motor back in operation.

#### 6.1.2.11 After and oil coolers

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Pliers, allen keys.

#### Maintenance

#### External surfaces:

- Isolate the machine from the service line
- Vent the separator tank pressure before attempting maintenance
- Open both the LH panel and cooler inspection cover
- Use compressed air below 2.5 bar/36.3 psi maximum to clean the outer surface of the cooler. Supply a jet of air in the direction opposite to cooling airflow direction
- After cleaning the outer surface of the cooler properly close the cooler with a cleaning plate and an LH panel.



COMPRESSED AIR JET Figure 31. Cooler external surface

## 6.1.2.12 Cooler prefilter accessory (optional)

#### Cooler prefilter cleaning & maintenance instructions

- Switch off the machine.
- Lift upward & take out the cooler pre filter from the compressor.
- Hold or fix the prefilter assembly in the cleaning area.
- Clean the pre-filter with compressed air at less than 2.5 bar.g (36.3 psi.g) from the reverse / back side of the cooler prefilter.
- In case of major dust / dirt accumulation in the prefilter element, wash with clean water or light detergent. Do not rinse.

- Do not use any acidic / alkaline chemicals for cleaning.
- Repeat the process based on dust conditions or regular periodic intervals.



Figure 22. Cooler prefilter accessory

## 6.1.2.13 Drive coupling



Figure 23. Drive coupling

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Spanners, new coupling element.

#### Maintenance

Replacing the coupling element:

- Open the cooler side panel covers
- Open the coupling guard from the adapter ring .
- Remove the three coupling screws and slide coupling element on the shaft spline to free the coupling element
- Replace the old coupling element with a new coupling
- element
- Tighten the coupling screws to the specified torque
- Assemble the coupling guard and cooler side panel cover
- Inspect every three months to ensure screws stay tight.

# 6.1.2.14 Moisture separator and auto drain valve

#### Pre work

- Switch off the compressor and disconnect power supply to the compressor.
- Close the discharge end ball valve.
- Release air oil tank pressure and allow the tank to cool for a few minutes.

#### Requirements

• Spanner, screw driver, player, caustic soda.

#### Maintenance

#### Dismantling

Disconnect the pressure sensor line on top of the moisture separator

- Manually drain the condensate by using the manual discharge plug located at the bottom of the auto drain assembly.
- Remove the moisture separator from the machine
- Remove the bottom housing from the top housing.
- Remove the auto drain assembly from the bottom housing.

#### **Cleaning and replacement**

- Inspect the O-ring and replace it with new one in the kit, if necessary
- Clean the housing and all other inner parts
- Ensure the mating surfaces of the O-ring are clean and free from foreign particles
- The auto drain assembly is not serviceable and must be replaced with new one if not functioning

#### Reassembly

- The vortex generator cone and the cyclone arrestor need only to be tightened moderately by hand. Overtightening may lead to failure or damage. ELGi assumes no responsibility for failure or damage resulting from such incorrect installation.
- Reassemble the auto drain assembly with the bottom housing and the bottom housing with the top housing
- Reassemble the moisture separator in the machine and connect the all pipe lines, pressure sensing line, and drain line
- Restart the machine and check for any leaks at the joints. If leaks occur, stop machine and wait for sump pressure to drop to atmospheric pressure.
- Remove the O-ring as described above, and inspect and clean it
- Ensure that the mating surfaces are clean and refit the O-ring

## **WARNING**

Moisture separator may be heavy. Caution should be taken while removing it from the machine.

## NOTE

- Avoid damaging the housing when removing or tightening the moisture separator. Do not use a pipe wrench. If necessary, use a locking strap clamp/wrench
- Install the separator in a vertical upright position, observing the correct direction of air





## 6.1.3 Use genuine spare parts

It is very important to use genuine spare parts, to ensures that your compressor work as new for its lifetime. Spurious spares may seem less expensive initially, but they severely compromises on quality. Spurious parts will prove cost-ineffective in the long run, and may even result in total damage of the machine or cause serious accidents. The table includes certain critical spurious parts. It is not an exhaustive list, and you are strongly advised to avoid all other spurious spares that this table does not cover. Be aware of the consequences of using spurious spares including but not limited to the ones described in the table.

Effect	Spurious part	Remarks
Higher power consumption	Air oil separator	Due to dense filtration media, it creates in additional pressure drop and so causes additional power consumption. Every1 bar (14.5 psi) of pressure drop results in $\sim$ 7% additional power consumption.
	Lubricant	Spurious oil loses its properties soon and may get solidified causing the rotor to malfunction.
	Air oil separator	This imposes 10% additional resistance for air flow and creates more pressure drop and thus additional load on motor. Inadequate separation deteriorates air quality, reduce the performance, and damages downstream components. It also results in huge oil loss (1L / 200hr).
performance	Oil filter	Contaminants are not filtered properly and the contaminated oil affects the critical parts of airend. Thus it reduces performance and life (33% reduction) of the air end, air oil separator etc. Contaminated oil also cause clogging and reduces the cooler performance.
	Air filter	Dust carries over to the system and causes the same problems as caused by the spurious oil filter
Safety hazard	Air oil separator	Inadequate earthing can cause a separator to collapse (25% risk). Inadequate earthing can also cause fire and destroy the entire machine.
Cost		<ul><li>Higher power consumption means a higher operating cost.</li><li>Reduced performance leads to extra functioning and operating cost.</li><li>Spurious parts will damage the other components and accelerate maintenance frequency and cost.</li><li>Higher consumption of consumables like oil (due to the use of spurious parts) will result in, increased cost.</li></ul>

\_\_\_\_ • • • \_\_\_\_\_

## 6.2 Troubleshooting



This guide lists the most likely indications with possible causes. For any problem, follow the diagnosis in sequential order as mentioned in the following charts. Before doing any work in the compressor, be sure that electrical supply has been cut off and the entire compressor is depressurized.

Problem	Cause	Solution (go sequentially)
	Power supply not available	Restore incoming power supply
		(1) Correct the incoming voltage.
	Incoming voltage is below limit	(2) Ensure isolator is within 5m (16 ft) from the compressor.
		(3) Ensure sufficient power back up
		(4) Select and use the correct cable size.
	Emergency stop switch in pushed	Rotate counter clockwise direction and release
	Emorgoney stop switch malfunction	Clean or replace the emergency switch.
	Emergency stop switch manufaction	Tighten the wires at terminals
		(1) Select correct fuse rating from selection chart.
	Icolator fuco blown	(2) Check and correct the short circuit within the control panel.
	Isolator fuse blown.	(3) Dedicated isolator to be provided to the compressor.
		(4) Check and correct the motor winding/ body short after
		Correct incoming voltage.
	Incoming phase-to-phase voltage imbalance of more than 5V	Adjust main incoming transformer tapping.
Compressor not starting		Correct the power factor to less than unity.
	Incoming phase to earth voltage	Correct the incoming voltage.
	Control MCB malfunction	Replace MCB
	Control fuses inside compressor control panel blown	Check for any short circuit or loose connection.
		Replace the solenoid valve / control transformer if defective.
		Replace the glass fuse (2A for Neuron, 1A for the control circuit).
	Control transformer fuse blown	Replace the control transformer if defective.
		Replace glass fuse (0.25A for Neuron, 0.5A for the control circuit).
		(1) Replace control transformer fuses.
	No power supply to Neuron controller.	(2) Ensure tight connection of the 24V power supply connector
		(3) Replace control transformer (50VA).
	No display in Neuron controller	(1) Replace the control transformer (50VA).
		(2) Replace the control fuse.
		(3) If 24V power supply to Neuron is okay then replace with anew Neuron micro controller.

Problem	Cause	Solution (go sequentially)
	Oil level is low	(1) Check and refill oil to correct the level. (in stopped condition)
		(2) Refer diagnosis procedure for high oil carry over.
		(3) Arrest oil leaks
		(4) Ensure the correct grade of oil is used.
	Room temperature is higher than outside ambient temperature by 30°C (86°F)	Improve ventilation in compressor room
		Clean the cooler assembly / cooler pre filter mesh (if available) externally by first using a fibre brush and then blowing compressed air at 2.5 bar.g(36.3 psi.g).
	Oil cooler clogged externally	For sticky dust, remove the cooler, close all the cooler ports with dummy plugs and do a water-wash with soap oil.
		Install the cooler prefilter mesh.
	Cooling fan rotating in wrong	Check and correct the wiring connection to the cooling fan.
	direction.	Replace with correct fan type.
		Replace the fuse if blown.
	Check fan motor fuse	Replace with the 2A fuse.
High discharge	Cooling fan not working.	Check and ensure the neutral connection is connected.
oil temperature	Tomporaturo concor malfunction	Replace the sensor.
	remperature sensor manufiction	Tighten/recrimp the connection with adaptor.
		Replace oil filter.
	Oil filter clogged	If required replace the oil (based on the condition of oil) and run the compressor.
	Thermal valve malfunctioning	Replace the thermal valve element.
	Oil injection orifice chocked or improper size	Clean the oil injection orifice.
		Replace with correct size.
	Air filter clogged	Clean or replace the air filter
		Check pressure drop is less than 1bar (14.5 psi).
	Separator element clogged	Replace oil.
		Replace separator element.
	Poor quality of oil	Replace oil.
	Oil cooler clogged internally	Check for pressure drop across the oil cooler if less than 1.5 bar (22 psi).
		Check and clean the cooler internally with 20L of isopropyl alcohol + toluene mixture in the 1:1 ratio and circulate for 4 hours with external 1 HP pump.
		Refit the cleaned cooler and, if required, replace oil (based on condition of the oil) and run the compressor.



Problem	Cause	Solution (go sequentially)
	High oil level	Drain excess oil and maintain the recommended oil level.
	Oil is milky	Replace oil and maintain the recommended level.
	Scavenge return line non return valve	1) Remove the return line NRV/orifice and clean it thoroughly.
	(NRV)/ orifice clogged	2) Change/clean the air filter.
	Scavenge return line tube clogged	Remove and clean the clogged scavenge return line tube.
	Scavenge return line tube gap not maintained (not applicable EG11 to EG22)	Remove the return line tube from the separator and correct it.
	The spin-on separator internal pipe thread damaged (applicable to EN series)	Replace the internal pipe.
High oil carry over	High discharge oil temperature (DOT)	Refer to the diagnosis procedure for high DOT.
	Improper grade of oil	Use ELGi recommended Air lube oil.
	Separator punctured/collapsed (not applicable to EG11 to EG22 units)	Replace with new separator.
	Separator element bonding ruptured (not applicable to EG11 to EG22 units)	Replace with new separator.
	Compressor runs at lower pressure than normal pressure.	1) Use suitable higher capacity compressor or match demand to compressor capacity.
		2) Arrest all line leakages.
	Minimum pressure valve (MPV) opening earlier than at the specified opening pressure* 4.5 bar.g (65.26psi.g). * 3.5 bar.g ( 50.8 psi.g) for compressors with working pressure 4.5 bar.g	Replace MPV kit/assembly.
	Neuron microcontroller pressure settings: 1) Unload pressure set value is above specification. 2) High tank pressure set value is below specification.	Check and correct the unload pressure and high tank pressure values in Neuron micro-controller
	Intake valve malfunction	1) Check and replace intake valve kit if required.
		2) Check the solenoid valve and clean or replace if required.
		3) Check and replace the actuator kit if required.
High tank pressure	BDV malfunction	Check/replace
	Compressor started with air outlet ball valve closed	Open the outlet ball valve.
	Solenoid valve malfunction	Check the solenoid valve and clean or replace if required.
	Neuron microcontroller malfunction	Replace the Neuron microcontroller
	Pressure transmitter malfunction	Replace the pressure transmitter
	MPV stuck up (check with pressure gauge in AOS tank )	Replace the MPV kit.
	Separator element choked	Replace the separator element

# ELGi

Problem	Cause	Solution (go sequentially)
	No control air supply to solenoid valve	Replace / connect
	Solenoid valve malfunctioning	1. Replace the solenoid valve assembly
		2. Clean the orifice
	No electrical supply for energising the solenoid valve	Replace the Neuron microcontroller
	Intake valve malfunctioning	Check and replace the intake valve kit.
	Diau daun valva malfunationina	1. Clean or change BDV assembly.
	Blow-down valve mairunctioning	2. Clean the orifice.
		1. Check and change the MPV kit.
	MPV malfunctioning	2. Check and change the MPV assembly
	Pressure regulator (applicable only to EG 55 to EG 250) setting lower than working pressure	1. Check and reset the pressure regulator setting to working pressure+0.3 bar (4.35 psi).
Loading/unloading		2. Change the pressure regulator assembly.
Problem	Actuator failure (applicable only to EG 55 to EG 250)	Check and change the actuator / kit / assy.
	1. Air requirement is more than compressor capacity	
	2. Working pressure is lower than required application pressure.	<ol> <li>Replace the compressor</li> <li>Arrest all pipeline leakages.</li> </ol>
	3. Excess pressure drop in pipe line.	
	Pressure transmitter malfunction	1. Tighten the lap cable
		2. Replace the lap cable
		3. Replace the pressure transmitter
		4. Replace the Neuron microcontroller
	Malfunction of R04 relay (loading/ unloading relay) in Neuron microcontroller	Replace the Neuron microcontroller
	Unload mode enabled in Neuron microcontroller	Disable 'unload mode' in operator settings of the Neuron microcontroller



Problem	Cause	Solution (go sequentially)							
	Inlet air pre-filter mat clogged	Clean/change pre-filter mat by following these steps: Switch off the machine. Squeeze and pull out the pre-filter mat from the canopy. Clean pre-filter with compressed air at less than 2.5 bar /36.3 psi Refit the filter after cleaning.							
	Clogged air filter element	Clean/change air filter element.							
	1. Air requirement is more than compressor capacity								
	2. Working pressure is lower than required application pressure.	<ol> <li>Replace compressor</li> <li>Arrest all pipeline leakages.</li> </ol>							
	3. Excess pressure drop in pipe line.								
	No control air supply to solenoid valve.	Replace / connect the control line tubes.							
		1. Replace the solenoid valve assembly							
	Solenoid valve mairunctioning	2. Clean the orifice							
Pressure not built up	No electrical control supply to solenoid valve	Replace the microcontroller							
	Intake valve malfunctioning	Check and replace intake valve kit.							
		1. Check and change the BDV assembly.							
	Blow down valve mairunctioning	2. Clean the orifice.							
		1. Check and change the MPV kit.							
		2. Check and change the MPV assembly							
	Pressure regulator (applicable only to EG 55 to EG 250) setting lower than working	1. Check and reset pressure regulator setting to working pressure+0.3bar (4.35 psi).							
	pressure	2. Change pressure regulator assembly.							
	Actuator failure (applicable only to EG 55 to EG 250)	Check/change actuator / kit / assembly.							
	Separator element choked (increase in pressure drop across separator)	Replace separator element. If required, replace the oil (based on condition of the oil) and run the compressor.							

# 6.3 Decommissioning, dismantling and putting out of service

If you do not intend to use the compressor or any of its parts, you must dismantle and putting out of service. These tasks must be carried out in compliance with the standards in force of that particular country.

## 6.3.1 Waste disposal

- Use of compressor generates waste. The residues from agricultural, industrial, crafts, commercial and service activities must be treated as waste, which needs to be disposed off properly. Deteriorated or obsolete machines are also classified as waste.
- Special attention must be given to active carbon filters as they cannot be included in urban waste. Observe the waste disposal laws in force where the compressor is used.
- It is mandatory to record loading or unloading of exhausted oils, obsolete machines and toxic harmful wastes that derive from heavy or light industry processes.
- It is especially important that exhausted oils be disposed off in compliance with the laws in the countries of use.

## 6.3.2 Dismantling the compressor

- Dismantle the compressor in accordance with all the precautions imposed by the laws in force in the country of use.
- Before dismantling, request an inspection by the relevant authorities. Disconnect the compressor from the electrical system.
- Eliminate any interfaces the compressor may have with other machines, making sure that interfaces between remaining machines are unaffected.
- Empty the air oil tank containing the lubricating oil and store in compliance with the laws in force.
- Proceed with the disassembly of the individual compressor components and group them together according to the materials they are made of: Steel, Stainless Steel, Aluminium and plastic parts.
- Then scrap the machine in compliance with the laws in force of the country of use.

## 6.3.3 Decommissioning the compressor

- Remove the foundation for the compressor.
- Unplug the power cable entry to the compressor.
- Drain the oil from the cooler and air oil tank. Dispose of it properly.
- Make sure all the compressed air is vented out through ball valves and safety devices residing in the compressor.
- Ensure that all the external supply lines have been properly disconnected from the compressor before decommissioning.

# 6.3.4 Disposal of consumables and replaced parts

• The moisture condensate separated from the compressed air contains oil particles. Disposal of condensate and filter element is to be done in accordance with the pollution control norms prevailing at the time of compressor installation or use.

ELGi

- Parts of the compressor that are replaced have metal and rubber components. These may be recycled and disposed off according to pollution control regulations, respectively.
- Rubber items such as AVMs, coupling elements, and Orings should be disposed and replaced before running again.

## NOTE

*ELGi is not responsible for the disposal of old oil or condensate. It is the responsibility of customer to dispose of the foregoing in accordance with local environmental statutory laws.* 

## 

The compressor does not give any warnings during short operating times. If it is operated below the dew point and moisture condensate may mix with oil. This will reduce the lubricating quality of the oil and lead to damage of compressor.

. . . -

## 6.4 ELGi Services

# 6.4.1 ELGi customer care system (ELGi CCS)

ELGi provides dedicated customer care and after-sales support through the ELGi customer care system (CCS), a computerized system developed in-house. The CCS aims to minimize the time taken to resolve customer complaints.

#### Service requests/complaints

The CCS toll-free telephone number 1800-425-3544 (accessible within India through BSNL and MTNL lines) takes the customer's call to our centralized customer care center in Coimbatore. Customers can register their service requirements or complaints here.

A unique tracking number is generated for each call logged by the CCS. The customer receives an automatic e-mail acknowledgement with the tracking number and details of the call for reference.

A service engineer is assigned to the call, and the date and time of the engineer's visit are communicated to the customer by e-mail. Every requirement or complaint must be resolved and closed in the CCS within a specified time limit, failing which the complaint is automatically brought to the notice of the manager. If the issue remains unresolved, it will get escalated to the managing director. The CCS ensures that not only the customer complaints are logged but they are also attended to on time, every time.

#### Enquires

A number of calls received by the CCS relate to customer queries regarding products and spare parts. The details are noted, and basic information on product specifications and usage are provided. The caller is then referred to a salesperson at the head office or the appropriate branch for follow-up.

#### The CCS database

The CCS also creates a database of customers, adding details of every new customer who calls, thereby building a large pool of installation details. These details are used to provide value-added services to improve customer satisfaction with ELGi products.

#### **CCS-working hours**

The ELGi CCS works for six days a week from 08:30 to 21:30 IST (Monday to Saturday).

#### **Multi-lingual capability**

The coordinators at the CCS are multi-lingual. They can handle calls in English and all the major regional languages of India.

**Coverage:** The CCS toll-free number 1800-425-3544 is accessible from the following areas:

• Southern Region: Tamil Nadu, Karnataka, Kerala, Puducherry, Andhra Pradesh, Telangana, Andaman & Nicobar Islands.

ELGi

- Western Region: Maharashtra, Gujarat, Madhya Pradesh, Goa, Lakshadweep Islands.
- **Eastern Region:** Orissa, Chhattisgarh, Jharkhand, West Bengal, Bihar and the North-Eastern states.
- Northern Region: Rajasthan, Uttar Pradesh, Delhi, Haryana, Punjab, Uttaranchal, Himachal and Jammu & Kashmir.

**Contact Numbers:** You can contact CCS also with the following numbers:

**Telephone:** 0422-2589206 / 241 / 242 / 243/ 244 / 245 / 97900 21100

Fax: 0422-2589240

Please send the following details to the mail, thus enable us to take immediate action.

- 1. Name of the customer
- 2. Compressor model
- 3. Fab. number
- 4. Contact person name
- 5. Phone number
- 6. Nature of complaint
- 7. Hour meter reading

You may use the CCS by sending e-mail to: ccs@elgi.com

#### **Customer satisfaction survey**

If you have used the CCS, you may be contacted for your feedback on our after-sales support. Your response helps ELGi to improve its service.

#### International customers:

Refer contact information at the end of this manual book

## 6.4.2 ELGi genuine spare parts

When ordering spare parts, refer to the lists provided in the parts manual and identify the part number. Specify the part number and quantity, in addition to the name plate details. Global support center of ELGi ensures the supply of the quality spares on time. Ensure that you are using the genuine spare parts so that your Compressor will be working efficiently and effectively. Refer to section 6.1.3 for details on need of using genuine spares.

Please contact our After sales team for any compressor accessory requirements like VFD, Air-Dryer, etc.

## 6.4.3 Air audit

We extend our proven capabilities in energy efficiency initiatives by carrying out air audits for our customers.

ELGi conducts audits and trains end users in key energy oriented functional areas. The audit reports prepared by ELGi experts' team include recommendations on short, medium and long term measures for energy conservation, along with financial estimates and analysis for implementation.

This air audit objective is to provide the customer:

- The framework for systematic collection of data relevant to the efficient operation of compressed air systems.
- A thorough analysis about the performance of the compressed air system, identifying potential electricity savings and to provide sound recommendations for implementation of energy efficiency initiatives.

Data analysis will be comprised of the information about different areas such as air leakages, inappropriate use of compressed air, compressed air system network, compressed air system supply including compressor internal maintenance conditions and even more.

The final report issued to the customer end will serve the purpose of assisting concise, consistent and complete presentation of the analysis, findings and recommendations arising from a compressed air system audit.

Depending on the measurement, reporting and cost requirements from the customer end, the intensity in level of audit (base level or investment level) will be decided. Also post implementation monitoring after air audit will be provided if requested from the customer end.

For further information on air audit contact ELGi.

E-Mail: ccs@elgi.com

\_\_\_ • • • \_\_\_\_\_



## 6.5.1 Conversion tables

Description	From	То	Multiply by				
	Inches	Millimetres	25.4				
	Metres	Inches	39.37				
Longth (L)	Feet	Millimetres	304.8				
Length (L)	Metres	Feet	3.281				
	Inches	Thou	1000				
	Millimetres	Micrometres	1000				
	Square metres	Square feet	10.765				
Area (A)	Square feet	Square inches	144				
	Square inches	Square millimetres	645.16				
	Cubic metres	Cubic feet	35.315				
	Cubic feet	Cubic inches	1728				
	Cubic metres	Litres	1000				
volume (v)	Cubic feet	Litres	28.32				
	US gallons (liq)	Litres	3.785				
	Imperial gallons (liq)	Litres	4.546				
	Cubic feet per minute (cfm)	Cubic metres per hour (m <sup>3</sup> /h)	1.6988				
) (alumatuia flaur (O)	Cubic feet per minute (cfm)	lpm	28.32				
volumetric flow (Q)	Cubic metres per hour (m <sup>3</sup> /h)	lpm	16.667				
	Cubic metres per minute (m <sup>3</sup> /min)	lps	16.667				
	Kilograms	Pounds	2.205				
Mass (M)	Kilograms	Grams	1000				
	Kilograms	Ounces	35.27				
	kg f/cm <sup>2</sup> g	psi g	14.223				
	psi g	Pascal	6895				
Pressure (P)	bar g	kg f/cm <sup>2</sup> g	1.0197				
	bar g	psi g	14.503				
	psi g	kg f/cm <sup>2</sup> g	0.0703				
	Degree Celsius (°C)	Degree Fahrenheit (°F)	°F = 9(°C)/5 +32				
Temperature (T)	Degree Celsius (°C)	Kelvin (K)	K = °C + 273.15				
	Degree Fahrenheit (°F)	Degree Rankine (°R)	°R = °F + 460				
	ft-lb f	Joules	1.35582				
	ft-lb f	Btu	0.001285				
Heat (q), Work (W), Energy (E)	Joules	Calories	0.2388				
	Btu/h	Calories/h	252				
	Kilowatts	Btu/h	3411				
Dowor (D)	Metric horsepower	Kilowatts	0.7355				
Power (P)	Imperial horsepower	Kilowatts	0.7457				

Table 8: Conversion table

## 6.5.2 Torque values

The tightening torque values for bolts and screws used in ELGi Compressors are provided in this section for reference. The tolerance for the torque values is (-) 10% from the given value.

Thread size*	Tightening torque (N-m)	Tightening torque (lb-ft)
M4	2.9	2.13
М5	5.7	4.20
M6	9.8	7.22
M8	24	17.7
M10	47	34.66
M12	81	59.73
M16	197	145.28
M20	385	283.93

Table 9: Metric hexagonal head bolts and screws

Thread size (inches)	Tightening torque (N-m)	Tightening torque (lb-ft)
1⁄4"	45	33.19
1⁄2"	85	62.69
3⁄4"	170	125.38
1"	330	243.39
1¼"	430	317.15
11/2"	510	376.15

## Table 10: BSP threads

Thread size (inches)	Tightening torque (N-m)	Tightening torque (lb-ft)
9/16"	149	109.8875
7/8"	579	427.0125

Table 11: UNF threads

\* Property class of 8.8 only

Operator sign										
Comments										
Trip record descrip- tion										
Cooler cleaning										
Pre Filter Cleaning										
Moisture removal from AOS tank	Before starting									
Oil level in AOS tank	Low/ normal/ high/ change									
Discharge temperature										
System pressure										
Line pressure										
Total operated hours / day										
Ē	Stop									
From	Start/ Tim									
Date										

## 6.5.3 Service log book – record of maintenance

## 6.6 Disclaimers

Please read this document and the warranty terms accompanying the product carefully before using our product. By purchasing our product, you agree that you will assume total responsibility and risk for your use of the product. The warranty terms of the product have been provided separately.

- 1. ELGi is not liable for failure of the compressor ( hereinafter "compressor" or "product") to perform its obligations if such failure is as a result of Acts of God (including but not limited to fire, flood, earthquake, storm, hurricane or other natural disaster), war, invasion, act of foreign enemies, hostilities (regardless of whether war is declared), civil war, rebellion, revolution, insurrection, military or usurped power or confiscation, terrorist activities, nationalization, government sanction, blockage, embargo, labour dispute, strike, lockout or interruption or failure of electricity or telephone service and any other reasons beyond ELGi's control.
- 2. ELGi does not take responsibility for any damage or injury resulting from neglecting the safety instructions, warnings, cautions, precautions, or non-observance of the normal caution and care required for installation, operation, maintenance and repair of the product, even if not expressly stated, and such instances are specifically disclaimed by ELGi.
- 3. The entire literature including product description or any other information in this manual exclusively belongs to ELGi and is subject to copyright. No person has any right to copy, modify, distribute, transmit, display, perform, reproduce, publish, license, create derivative works, transfer or sell any information, or deal with the same in any other manner, without the knowledge and written concurrence of ELGi, violation of which would amount to infringement of rights of ELGi and would necessitate legal action.
- 4. The information published in this manual may include inaccuracies, or typographical errors. Changes may be periodically added to the information herein. Any changes/improvements may also be made to the products stated in this manual and ELGi is not liable if the readers are not updated with information.
- 5. Likewise ELGi is responsible only till the point of first sale to the ultimate customer and not thereafter and only if the product is purchased from authorized dealers of ELGi. ELGi disowns liability on account of purchase of any second hand product or purchase otherwise from unauthorized dealers. ELGi shall not be liable for any indirect, incidental, punitive, special or consequential losses or damages including any loss of profit, loss of production, loss of income or contract, loss of goodwill, expected savings or business relationships, arising out of or in any way connected with the usage of the product or information in this manual.
- 6. In no event ELGi shall be liable for any claims or loss having a value higher than the original purchase price of the product sold by ELGi or its network of authorised dealers.
- 7. These Disclaimers and the contents of this manual shall be subject to the laws of India and any disputes pertaining to this manual or anything stated therein or any product stated therein is subject to the exclusive jurisdiction of the courts in Coimbatore, Tamil Nadu, India.
- 8. No liability in connection with the product will accrue to ELGi,
- If any welding or related operation involving heat is carried out in the compressor. Never weld or modify any parts including pressure vessels.
- If any damages to the product directly or indirectly arise due to long storage (6 months) of product and subsequent corrosion of internal parts and which leads to fire or malfunctioning of the product.
- If the compressor package and its accessories are installed in such a way to allow moisture, rain, freezing temperature or sun damage to affect the safe operation of the unit.
- If the person who operates / maintains the compressor does not adhere to all work related safety practices and regulatory requirements.
- If unauthorized personnel other than ELGi authorized or trained personnel carries out commissioning, installation, operation, maintenance and any repair work on the compressor.
- If the compressor and the compressed air are used for unintended use or are misused.
- If the compressor is operated below or in excess of its pressure and temperature limits.
- If the compressor "ON/ OFF" switch is operated through remote control situated away from the compressor location without giving any adequate notice / alarm before starting the product .
- © Copyright ELGi Equipments Limited, India 2018. All Rights Reserved.

Maintenance

Fi Gi





Ιr						_									_					<u> </u>						Т					Т		<u>د</u> ۱	ե
1																									DELANDARG		ELGI EQUIPMENTS LTD.,	COIMBATORE - INDIA.		IERIALO	SSY.	83 6245 4	8 REVISION R 0 4	HIS DRG. IF IN DOUBT, ASK ENGG. DEF
																										į	U			¥≥ L	NEXT AS	01	33 of	T SCALE TH
		qτγ	Э	-	-	-	-	-	-	18	2	ю	12	I	I	I	I	1	٢	-	1 SET		-	-			IJ	J				DRG.No.	DRG.SHEET	9 00 00
	*	ţ.	0	510023 510024 510025 510019	6	0	26	Ş	2 2	42	20	0	5	A	A S	¥	ŞA	•	20						2 2	;						L L	]	
2	01836245	Si PART N	00893207	B0120005 B0120005 B0120005 B0120005	01836274	5100890015	00894623	00893703	00893703	01836273	01836273	00894622	01836273	00894641	00894642	00894644	00894646	X0180912	00894003	1	18400109		N2067980	8400078		BOH-	71.000				DRG.No.		サ の	2
	: NAME :	ELC																					ĕ	0		G11-22V 460V	A00+ A 77-110		Ħ	11.12	11.12 RPF.		z	
	CAD FILE							0-24V												NG					2002				ME	01.	× 101.			
			H COVER		1-1AB00	-1AB01		30-230V/	·24V					N	N	N	wo			TIN COATI	000-					. CONT		AT'L.	ž	SIGNED	<u>م</u> ر	ECKED	PD.	
£	ATERIALS	ING	-6FEO WIT	W (15HP) W (20HP) W (25HP) W (30HP)	3RH21 3	3RT20 16-	1192	VA 0-0-2	A,0-24/0-	-101	-107	10U	-611	SLOW BLO	SLOW BLO	SLOW BLO	" SLOW BL		AML4	PER WITH	-102/026 -1105 -1106 -1104	-204/026 -206/026 -203/026		000	E	2 3	ž	3		8	<u></u>	<u>5</u>	D.BY. AF	ы
	OF M/	RAT	RSC	11k 15k 18k	10Å,	9 <b>A</b> ,	296	150	CAL 40V	281	281	CTS	281	1A,	2A,	4A,	6.3A	1	P2/	COF	231 713 713 713 713	231 231 231 231	1	PT									K K	
	BILL	щ	ENIX	FOSS	IENS	IENS	ENIX	RON	ELECTRIC			ECTWELL		ECTRON	ECTRON	ECTRON	ECTRON		c				SS	SS									ALT.B	
		MA	РНО	DANI	SIEM	SIEM	DHO	PLITF	BASIC	WAGO	WAGO	CONN	WAGC	PROT	PROT	PROT	PROT	ELGI	TEKNI	I	WAGO		DANO	DANO										
+		NOL	S		ж			DRMER	RMER	AALS	NALS (Y/G)	3 TERMINALS	WTH GLASS FUSE					ER	USH BUTTON	COMPONENT EARTH WITH FLAT & SPRING WASHER	ц.		TER	OR									DESCRIPTION	4
		DESCRIP.	INCOMING TERMINAL	DRIVE	CONTROL CONTACTO	FAN CONTACTOR	CONTROL RELAY	MULTI TAP TRANSFO	CONTROL TRANSFOF	CONNECTING TERMI	CONNECTING TERMI	MOTOR CONNECTIN	FUSE TERMINALS V	GLASS FUSE	GLASS FUSE	GLASS FUSE	GLASS FUSE	NEURON CONTROLI	EMERGENCY STOP F	EARTH STRIP FOR 5mm SCREW WITH	PLC CONNECTER 5		PRESSURE TRANSMI	TEMPERATURE SENS									ATE	
<b>U</b> )		CODE	L1-L3	VFD	K2	K4	CR1	TR1	TR2	G,T	PE	MT	Ŀ	-	-	-	-	Ξv	E-STOP	PE	NNECTER		2S1	TS1										
		Ľ			1-	<b></b>	Ľ	<u> '</u>	L.	Ľ								-	E		<u>  8</u>		<u> </u>	Ľ									ECO.No	
9																																	REV. NO.	9
	1 R15	2 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	9'21 9'71	2.2 6.3 2.2 6.3 2.2 6.3 2.2 6.3 2.2 6.3	8°0 9N 	*0 GN ///	0.2 N4 N4		0.05 2N VV	97070 LN ()	שד SS3 רו SS3	E Ka CHN WBC	NUM NOA NS NOA	∓2 +000 (un)	00 00 90	5 ∓ 0 ≠0 0 50	∓1 500 001 7 S	9.0± 0001 215 SVN	10 N 120 215	073 703 0 150 2 20	NCE 70170	MACHINING N OVER N OVER N OVER	qoue DEN-	k pe d LIED CONEII	ubaux <sup>.</sup> niq oujx AL2 NW eut is ( EKMIZE ;	cou sµo bMEI conu 01HE	the orm EQUI SSS	ou ol aux l in fhi UNLE	mm ben i o i issim	c beu cobeu coura KE IN	VS A	the si oductic iforma iforma ENSIOI	with All in Mepri Alt Mith	

