

Operator's Manual

CP0611-D28H & CP0611-D28L Series
1" & spline #5 Impact Wrench





MWARNING

To reduce risk of injury, everyone using, installing, repairing, maintaining, changing accessories on, or working near this tool must read and understand these instructions, as well as separately provided safety instructions part number 6159948710, before performing any such task.

Air Diagram:




Fig. 1




Fig. 2




Fig. 3

	Drive	Torque				Inner hose		Air consumption		Sound		Vibrations	
		Working	Max	Speed	Weight	diameter	Dimension	'@ load	Air inlet	Pressure	Power	а	k
Model	→	F)	lb/kg	<u>↓</u>	I w	ř		\cap			
	1	2		3	4	5	6	7	8	9		10	11
	in.	ft.lbs N.m	ft.lbs N.m	rpm	lbs kg	in. mm	in. mm	SCFM NI/s	in.	dB(a)	dB(a)	m/s²	m/s²
CP0611-D28H	1"	900 - 1 800	300 2 800	2500	3500 22.5 10.4	1" 25	10.2*4.3*6.9 360*110*175	68 32	1/2" FEMALE	99	110	18.0	4.1
CP0611-D28L	Spline #5		3790	3300						99	33 110		4.1

Fig. 4

CP0611-D28H & CP0611-D28L Series

Impact Wrench

Technical Data (see Fig 5.)

Model		Torque				Inner Hose	Dimension	Air Consumption		Sound-	Sound-	Vibrations		
		Drive	Working	Max	Speed	Weight	Dia.	L x H x W	At load	Air Inlet	Pressure Power L _{pA} L _{wA}		ahd	k
	Model	■ →1≮	F		Ĺ.	lb/kg	→	L. W	=	₩	\bigcirc			
ı	į	1	2		3	4	5	6	7	8	9		10	11
L		[inch]	[ft.lbs] [Nm]	[ft.lbs] [Nm]	[min-1]	[lb] [kg]	[inch.] [mm]	[inch.] [mm]	[SCFM] [NI/s]	[inch]	[dB(A)]	[dB(A)]	[m/s ²]	[m/s²]

max pressure 6.3 bar (90 psi)

 \mathbf{a}_{hd} : Vibration level, **k** Uncertainty; \mathbf{L}_{nA} Sound pressure level dB(A), $\mathbf{K}_{nA} = \mathbf{K}_{wA} = 3$ dB Uncertainty.

Declaration of noise (ISO 15744) and vibration emission (ISO 28927-2)

All values are current as of the date of this publication. For the latest information please visit www.cp.com.

These declared values were obtained by laboratory type testing in accordance with the stated standards and are suitable for comparison with the declared values of other tools tested in accordance with the same standards. These declared values are not adequate for use in risk assessments and values measured in individual work places may be higher. The actual exposure values and risk of harm experienced by an individual user are unique and depend upon the way the user works, the workpiece and the workstation design, as well upon the exposure time and the physical condition of the user.

We, CHICAGO PNEUMATIC TOOLS, cannot be held liable for the consequences of using the declared values, instead of values reflecting the actual exposure, in an individual risk assessment in a work place situation over which we have no control.

This tool may cause hand-arm vibration syndrome if its use is not adequately managed. An EU guide to managing hand-arm vibration can be found at www. pneurop.eu/uploads/documents/pdf/PN3-02-NV_Declaration_info_sheet_0111.pdf

We recommend a programme of health surveillance to detect early symptoms which may relate to noise or vibration exposure, so that management procedures can be modified to help prevent future impairment.

Clutch Lubrication

1 oz. (30g).

Use CP Pneu-Lube Synthetic Clutch Grease 8940158455:

2. Machine Type

- This product is designed for installing and removing threaded fasteners in wood, metal and plastic. No other use permitted. For professional use only.
- Please read the product safety information carefully!

3. Implementation and Operation

- · Connect device as shown in Fig.1.
- Fix the accessories properly to the tool.
- To switch rotation, turn the switch (B) as shown in Fig. 3
- To start the machine, simply pull the trigger (A). Machine speed is increased by increasing pressure on the trigger. Release the trigger to stop.
- · Use the reverse switch (B) only when the drive spindle comes to a complete stop.

4. Lubrication

Motor Lubrication

Use an air line lubricator with SAE #10 oil, adjusted to two (2) drops per minute. If an air line lubricator cannot be used, add air motor oil to the inlet once a day. Recommended lubricant CP Oil PROTECTO-LUBE:

- 4 oz (0.12l) P/N: CA149661
- 20.8 oz (0.591I) P/N: CA000046 - 1gal (3.8l) P/N; P089507

5. Maintenance

- · Follow local country environmental regulations for safe handling and disposal of all components
- Disassemble and inspect the tool every three 3 months if the tool is used every day. Replace damaged or worn parts.
- Always ensure that the machine is disconnected from energy source (compressed air) to avoid accidental operation.
- High wear parts are underlined in the parts list.
- To keep downtime to a minimum, the following service kits are recommended: Tune-Up Kit: see part list

6. Disposal

- · The disposal of this equipment must follow the legislation of the respective country.
- All damaged, badly worn or improperly functioning devices MUST BE TAKEN OUT OF OPERATION.
- Repair only by technical maintenance staff.

7. Declaration of conformity

We: CHICAGO PNEUMATIC Tool Co. 1800 Overview Drive Rock Hill, SC 29730 - USA

Declare that the product(s): Impact Wrench

Machine type(s): CP0611-D28H, CP0611-D28L Serial Number: From 00001 to 99999

Origin of the product : Japan

is in conformity with the requirements of the council Directives on the approximation of the laws of the Member States relating : to "Machinery" 2006/42/EC (17/05/2006) applicable harmonised standard(s): EN ISO 11148-6:2012

Name and position of issuer: Nicolas Lebreton (R&D Manager)

Place & Date : Saint-Herblain, 22/09/2014

Technical file available from EU headquarter. Nicolas Lebreton R&D Manager LLC CP Technocenter 38, rue Bobby Sands - BP10273 44800 Saint Herblain - France

Copyright 2014, Chicago Pneumatic Tool Co. LLC

All rights reserved. Any unauthorized use or copying of the contents or part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers and drawings. Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

Original instructions



www.cp.com